

BAZR2.MH26866 - Batteries, Standby - Component

Batteries, Standby - Component

**LEOCH BATTERY SHENZHEN CORP**  
Unit E8,E9,E148,E149, 5F,Xinbaohui Bldg  
Nanhai Ave,Nanshan  
SHENZHEN, GUANGDONG 518052 China

MH26866

| Model                                                        | Capacity, Voltage, |      | Max       |         | Max    |      | Oper.  | Battery |           | High-rate |
|--------------------------------------------------------------|--------------------|------|-----------|---------|--------|------|--------|---------|-----------|-----------|
|                                                              |                    |      | Discharge |         | Charge |      | Range/ | Case    | Enclosure | Discharge |
|                                                              |                    |      |           |         |        |      | Max    |         |           |           |
|                                                              | Rate               | Rate | Rate      | Ambient | Flame  | Test | Test   | Current |           |           |
| Model                                                        | Ah                 | Vdc  | Amps      | Hr      | Amps   | Hr   | °C     | Rating  | Schedule  | Amps      |
| Sealed cell, lead acid batteries with pressure release vents |                    |      |           |         |        |      |        |         |           |           |
| 10OPzV1000                                                   | 1000               | 2    | -         | -       | -      | -    | -      | V-0     | -         | -         |
| 12OPzV1200, VGS1200                                          | 1200               | 2    | -         | -       | -      | -    | -      | HB      | -         | -         |
| 12OPzV1500                                                   | 1500               | 2    | -         | -       | -      | -    | -      | V-0     | -         | -         |
| 12V3OPZV100FT                                                | 100                | 12   | -         | -       | -      | -    | -      | HB      | -         | -         |
| 12V3OPzV100FT FR                                             | 100                | 12   | -         | -       | -      | -    | -      | V-0     | -         | -         |
| 12V3OPZV120FT                                                | 120                | 12   | -         | -       | -      | -    | -      | HB      | -         | -         |
| 12V3OPzV120FT FR                                             | 120                | 12   | -         | -       | -      | -    | -      | V-0     | -         | -         |
| 12V3OPzV150FT FR                                             | 150                | 12   | -         | -       | -      | -    | -      | V-0     | -         | -         |
| 12V4OPZV150FT                                                | 150                | 12   | -         | -       | -      | -    | -      | HB      | -         | -         |
| 16OPzV2000                                                   | 2000               | 2    | -         | -       | -      | -    | -      | V-0     | -         | -         |
| 235-011-009, STK12-9.0, LP12-10S, ES1290                     | 8                  | 12   | -         | -       | -      | -    | -      | HB      | -         | -         |
| 24OPzV3000, VGS3000                                          | 3000               | 2    | -         | -       | -      | -    | -      | HB      | -         | -         |
| 3OPZV150, VGS160                                             | 150                | 2    | -         | -       | -      | -    | -      | HB      | -         | -         |
| 4OPzV200, VGS200                                             | 200                | 2    | -         | -       | -      | -    | -      | HB      | -         | -         |
| 5OPzV250, VGS250                                             | 250                | 2    | -         | -       | -      | -    | -      | HB      | -         | -         |
| 5OPzV350, VGS350                                             | 350                | 2    | -         | -       | -      | -    | -      | HB      | -         | -         |
| 6-EV-53                                                      | 53                 | 12   | -         | -       | -      | -    | -      | HB      | -         | -         |
| 6-EVF-50                                                     | 50                 | 12   | -         | -       | -      | -    | -      | HB      | -         | -         |
|                                                              |                    |      |           |         |        |      |        |         |           |           |
| 6OPzV300                                                     | 300                | 2    | -         | -       | -      | -    | -      | V-0     | -         | -         |
| 6OPzV400, VGS400                                             | 400                | 2    | -         | -       | -      | -    | -      | V-0     | -         | -         |

|                               |       |    |   |   |   |   |   |     |   |   |
|-------------------------------|-------|----|---|---|---|---|---|-----|---|---|
| 6OPzV420, VGS400              | 420   | 2  | - | - | - | - | - | V-0 | - | - |
| 6OPzV600                      | 600   | 2  | - | - | - | - | - | V-0 | - | - |
| 7OPzV490                      | 490   | 2  | - | - | - | - | - | V-0 | - | - |
| 8OPzV800                      | 800   | 2  | - | - | - | - | - | V-0 | - | - |
| AGM12V-105AH                  | 108   | 12 | - | - | - | - | - | HB  | - | - |
| BW121000                      | 110   | 12 | - | - | - | - | - | HB  | - | - |
| BW12140                       | 14    | 12 | - | - | - | - | - | HB  | - | - |
| CPS5.5-12 FR                  | 5.5   | 12 | - | - | - | - | - | V-0 | - | - |
| CT3,2-12 FR, ELA-12V-3.4AH FR | 3.2   | 12 | - | - | - | - | - | V-0 | - | - |
| CT3,2-6 FR, ELA-6V-3.4AH FR   | 3.2   | 6  | - | - | - | - | - | V-0 | - | - |
| DG100                         | 106   | 2  | - | - | - | - | - | HB  | - | - |
| DG130                         | 138   | 2  | - | - | - | - | - | HB  | - | - |
| DG150                         | 159   | 2  | - | - | - | - | - | HB  | - | - |
| DG170, DGM-170                | 181.3 | 2  | - | - | - | - | - | HB  | - | - |
| DG200                         | 212   | 2  | - | - | - | - | - | HB  | - | - |
| DG450                         | 480   | 2  | - | - | - | - | - | HB  | - | - |
| DG65                          | 69    | 2  | - | - | - | - | - | HB  | - | - |
| DGM12100 FR                   | 100   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12100, DGM12120S           | 110   | 12 | - | - | - | - | - | HB  | - | - |
| DGM12110 FR                   | 110   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12120 FR                   | 120   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12125                      | 125   | 12 | - | - | - | - | - | HB  | - | - |
| DGM12125 FR                   | 125   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12135 FR                   | 135   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12135, DGM12150S, DGM12120 | 140   | 12 | - | - | - | - | - | HB  | - | - |
| DGM12140 FR                   | 140   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12150                      | 150   | 12 | - | - | - | - | - | HB  | - | - |
| DGM12150 FR                   | 150   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12160 FR                   | 160   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12170 FR                   | 170   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12190 FR                   | 190   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12200 FR                   | 200   | 12 | - | - | - | - | - | V-0 | - | - |
| DGM12200, DGM12200S           | 200   | 12 | - | - | - | - | - | HB  | - | - |

|                                                      |     |    |   |   |   |   |   |     |   |   |
|------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>DGM12200, DGM12200S</b>                           | 200 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM12210 FR</b>                                   | 210 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM12230 FR</b>                                   | 230 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM12230, LPG12-240</b>                           | 230 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1235 FR</b>                                    | 35  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1235, DGM1238S</b>                             | 38  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1238 FR</b>                                    | 38  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1240 FR</b>                                    | 40  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1245 FR</b>                                    | 45  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1245, DGM1245S</b>                             | 40  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1250 FR</b>                                    | 50  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1250(I), DGM1250S, DGM1250</b>                 | 50  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1250(II), LPCG12-60, LPG12-60H, LPCG12-60I</b> | 50  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1255 FR</b>                                    | 55  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1255(I)</b>                                    | 55  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1255(II), DGM1265S, DGM1260</b>                | 55  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1255(III)</b>                                  | 55  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1260 FR</b>                                    | 60  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1265 FR</b>                                    | 65  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1265, DGM1270S</b>                             | 70  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1270</b>                                       | 75  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1270 FR</b>                                    | 70  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1275 FR</b>                                    | 75  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1280 FR</b>                                    | 80  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1280, DGM1290S</b>                             | 85  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1285 FR</b>                                    | 85  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1285, DGM12100S</b>                            | 90  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DGM1290 FR</b>                                    | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1290S FR</b>                                   | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM1296 FR</b>                                    | 96  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DGM6150</b>                                       | 150 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DGM6200</b>                                       | 200 | 6  | - | - | - | - | - | HB  | - | - |

|                    |      |    |   |   |   |   |   |     |   |   |
|--------------------|------|----|---|---|---|---|---|-----|---|---|
| DGW12-12           | 10   | 12 | - | - | - | - | - | HB  | - | - |
| DGW12-18           | 15   | 12 | - | - | - | - | - | HB  | - | - |
| DGW12-24           | 24   | 12 | - | - | - | - | - | HB  | - | - |
| DGW12-24H          | 24   | 12 | - | - | - | - | - | HB  | - | - |
| DGW12-33           | 31   | 12 | - | - | - | - | - | HB  | - | - |
| DGW12-7.0          | 7    | 12 | - | - | - | - | - | HB  | - | - |
| DJ100              | 100  | 2  | - | - | - | - | - | HB  | - | - |
| DJ100 FR           | 100  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ1000             | 1000 | 2  | - | - | - | - | - | HB  | - | - |
| DJ1000 FR, DJ1000M | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ1000H            | 1000 | 2  | - | - | - | - | - | HB  | - | - |
| DJ1000H FR         | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ120              | 120  | 2  | - | - | - | - | - | HB  | - | - |
| DJ1200             | 1200 | 2  | - | - | - | - | - | HB  | - | - |
| DJ1200 FR          | 1200 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ1200H            | 1200 | 2  | - | - | - | - | - | HB  | - | - |
| DJ1200H FR         | 1200 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ130              | 130  | 2  | - | - | - | - | - | HB  | - | - |
| DJ130 FR           | 130  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ150              | 150  | 2  | - | - | - | - | - | HB  | - | - |
| DJ150 FR           | 150  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ1500             | 1500 | 2  | - | - | - | - | - | HB  | - | - |
| DJ1500 FR          | 1500 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ1500H            | 1500 | 2  | - | - | - | - | - | HB  | - | - |
| DJ1500H FR         | 1500 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ1800             | 1800 | 2  | - | - | - | - | - | HB  | - | - |
| DJ1800 FR          | 1800 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ200              | 200  | 2  | - | - | - | - | - | HB  | - | - |
| DJ200 FR, DJ200M   | 200  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ2000             | 2000 | 2  | - | - | - | - | - | HB  | - | - |
| DJ2000 FR          | 2000 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ2000H            | 2000 | 2  | - | - | - | - | - | HB  | - | - |

|            |      |   |   |   |   |   |   |     |   |   |
|------------|------|---|---|---|---|---|---|-----|---|---|
| DJ2000H FR | 2000 | 2 | - | - | - | - | - | V-0 | - | - |
| DJ2500     | 2500 | 2 | - | - | - | - | - | HB  | - | - |

|                  |      |    |   |   |   |   |   |     |   |   |
|------------------|------|----|---|---|---|---|---|-----|---|---|
| DJ250            | 250  | 2  | - | - | - | - | - | HB  | - | - |
| DJ250 FR         | 250  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ2500           | 2500 | 2  | - | - | - | - | - | HB  | - | - |
| DJ2500 FR        | 2500 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ300            | 2500 | 2  | - | - | - | - | - | HB  | - | - |
| DJ300 FR, DJ300M | 2500 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ3000           | 3000 | 2  | - | - | - | - | - | HB  | - | - |
| DJ3000 FR        | 3000 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ3000H          | 3000 | 2  | - | - | - | - | - | HB  | - | - |
| DJ3000H FR       | 3000 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ350            | 350  | 2  | - | - | - | - | - | HB  | - | - |
| DJ350 FR         | 350  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ3500           | 3500 | 2  | - | - | - | - | - | HB  | - | - |
| DJ3500 FR        | 3500 | 2  | - | - | - | - | - | V-0 | - | - |
| DJ400            | 400  | 2  | - | - | - | - | - | HB  | - | - |
| DJ400 FR, DJ400M | 400  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ450            | 450  | 2  | - | - | - | - | - | HB  | - | - |
| DJ450 FR         | 450  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ500            | 500  | 2  | - | - | - | - | - | HB  | - | - |
| DJ500 FR, DJ500M | 500  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ600            | 600  | 2  | - | - | - | - | - | HB  | - | - |
| DJ600 FR, DJ600M | 600  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ600E           | 600  | 2  | - | - | - | - | - | HB  | - | - |
| DJ600E FR        | 600  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ65             | 65   | 2  | - | - | - | - | - | HB  | - | - |
| DJ65 FR          | 65   | 2  | - | - | - | - | - | V-0 | - | - |
| DJ700            | 700  | 2  | - | - | - | - | - | HB  | - | - |
| DJ700 FR         | 700  | 2  | - | - | - | - | - | V-0 | - | - |
| DJ75             | 75   | 2  | - | - | - | - | - | HB  | - | - |
| DJ75 FR          | 75   | 2  | - | - | - | - | - | V-0 | - | - |
| DJ760            | 35   | 12 | - | - | - | - | - | HB  | - | - |
| DJ800            | 800  | 2  | - | - | - | - | - | HB  | - | - |

|                  |     |   |   |   |   |   |   |     |   |   |
|------------------|-----|---|---|---|---|---|---|-----|---|---|
| DJ800 FR, DJ800M | 800 | 2 | - | - | - | - | - | V-0 | - | - |
|------------------|-----|---|---|---|---|---|---|-----|---|---|

|                                                                        |     |    |   |   |   |   |   |     |   |   |
|------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>DJ900</b>                                                           | 900 | 2  | - | - | - | - | - | HB  | - | - |
| <b>DJ900 FR</b>                                                        | 900 | 2  | - | - | - | - | - | V-0 | - | - |
| <b>DJM12100 FR, 6LCTM100 FR, DJM12100S FR</b>                          | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM12100, 6LCTM100, DJM12100S, 6-EV-100, LPGS12-100</b>             | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM12100H FR</b>                                                    | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM12110</b>                                                        | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM12110 FR</b>                                                     | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM12120 FR, DJM12120S FR</b>                                       | 120 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM12120, DJM12120S, 6-EV-120, LPGS12-120</b>                       | 120 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM12140 FR, DJM12140S FR</b>                                       | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM12140, DJM12140S</b>                                             | 140 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM12150 FR, DJM12150S FR</b>                                       | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM12150, DJM12150S, 6-EV-150, LPGS12-150</b>                       | 150 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM12180, DJM12180S</b>                                             | 180 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM12200 FR, 6LCTM-200 FR, DJM12200S FR,</b>                        | 200 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM12200, 6LCTM-200, DJM12200S, LHP12775W, 6-EV-200, LPGS12-200</b> | 200 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM12225</b>                                                        | 225 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM12225 FR</b>                                                     | 225 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM12230, DJM12230S</b>                                             | 230 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1224</b>                                                         | 24  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1224 FR</b>                                                      | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM12250</b>                                                        | 250 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM12250 FR</b>                                                     | 250 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1238 FR, DJM1238S FR</b>                                         | 38  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1238, DJM1238S, 6-EV-38</b>                                      | 38  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1240 FR, DJM1240S FR</b>                                         | 40  | 12 | - | - | - | - | - | V-0 | - | - |

|                                                                 |    |    |   |   |   |   |   |     |   |   |
|-----------------------------------------------------------------|----|----|---|---|---|---|---|-----|---|---|
| <b>DJM1240 PC, DJM1240S PC</b>                                  | 40 | 12 | - | - | - | - | - | V-2 | - | - |
| <b>DJM1240, DJM1240S, 6-EV-40</b>                               | 40 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1245 FR, DJM1245S FR</b>                                  | 45 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1245, DJM1245S, 6-EV-45</b>                               | 45 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1250 FR, DJM1250S FR</b>                                  | 50 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1250, DJM1250S</b>                                        | 50 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1255</b>                                                  | 55 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1255 FR</b>                                               | 55 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1255S</b>                                                 | 55 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1260 FR</b>                                               | 60 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1260, 6-EV-60</b>                                         | 60 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1265 FR, DJM1260S FR, DJM1265S FR</b>                     | 65 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1265, DJM1260S, DJM1265S, 6-EV-65</b>                     | 65 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1270</b>                                                  | 70 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1270 FR</b>                                               | 70 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1272</b>                                                  | 72 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1272 FR</b>                                               | 72 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1275 FR, DJM1275S FR</b>                                  | 75 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1275, DJM1275S, 6-EV-75</b>                               | 75 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1275H</b>                                                 | 72 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1275H FR</b>                                              | 72 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1280 FR, DJM1280S FR, LHR12255W, LHP12270W, LHP12340W</b> | 80 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1280, DJM1280S, 6-EV-80</b>                               | 80 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM1290 FR, LHR12330W, LHP12390W</b>                         | 90 | 12 | - | - | - | - | - | V-0 | - | - |

|                                     |    |    |   |   |   |   |   |    |   |   |
|-------------------------------------|----|----|---|---|---|---|---|----|---|---|
| <b>DJM1290, LPL12-100H, 6-EV-90</b> | 90 | 12 | - | - | - | - | - | HB | - | - |
|-------------------------------------|----|----|---|---|---|---|---|----|---|---|

|                                                        |     |    |   |   |   |   |   |     |   |   |
|--------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>DJM1290H FR, DJM1290S FR</b>                        | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJM1290H, DJM1290S</b>                              | 90  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJM6100 FR</b>                                      | 100 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJM6100, 3-EV-100</b>                               | 100 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJM6120</b>                                         | 120 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJM6120 FR</b>                                      | 120 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJM6150</b>                                         | 150 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJM6150 FR</b>                                      | 150 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJM6165</b>                                         | 165 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJM6180</b>                                         | 180 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJM6200 FR, 3LCTM-200 FR, DJM6200S FR</b>           | 200 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJM6200, 3LCTM-200, DJM6200S, 3-EV-200, ED62500</b> | 200 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJM660</b>                                          | 60  | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJM660 CP</b>                                       | 60  | 6  | - | - | - | - | - | V-2 | - | - |
| <b>DJM660 FR</b>                                       | 60  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-0.8</b>                                       | 0.8 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-0.8 FR</b>                                    | 0.8 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-1.2</b>                                       | 1.2 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-1.2 FR</b>                                    | 1.2 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-1.5</b>                                       | 1.5 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-1.5 FR</b>                                    | 1.5 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-1.8</b>                                       | 1.8 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-1.9 FR</b>                                    | 1.9 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-10</b>                                        | 10  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-10 FR</b>                                     | 10  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-10H</b>                                       | 10  | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-10H FR</b>                                    | 10  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-12 FR</b>                                     | 12  | 12 | - | - | - | - | - | V-0 | - | - |

|                                               |    |    |   |   |   |   |   |    |   |   |
|-----------------------------------------------|----|----|---|---|---|---|---|----|---|---|
| <b>DJW12-12, 12V12AH, LHP1252W, LHR1250W,</b> | 12 | 12 | - | - | - | - | - | HB | - | - |
|-----------------------------------------------|----|----|---|---|---|---|---|----|---|---|

|                                            |     |    |   |   |   |   |   |     |   |   |
|--------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| LP12-12S                                   |     |    |   |   |   |   |   |     |   |   |
| DJW12-14                                   | 14  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-14 FR                                | 14  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-15                                   | 15  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-15 FR                                | 15  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-17                                   | 17  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-18 FR, LHR1280W, LHP1285W            | 18  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-18, 6-DZM-18                         | 18  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.0                                  | 2   | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.0 FR                               | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-2.0C FR                              | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-2.0C, ES2-12V-X                      | 2   | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.0C1                                | 2   | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.0C1 FR                             | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-2.0NP                                | 2   | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.0NP FR                             | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-2.1 FR                               | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-2.1, LP12-2.1, 12LS-2.1, ES2.3-12V-X | 2.1 | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.3                                  | 2.3 | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.3 FR                               | 2.3 | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-2.3C                                 | 2.3 | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.3C FR                              | 2.3 | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-2.5                                  | 2.5 | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.5 FR                               | 2.5 | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-2.6 FR, CT2,6-12H FR                 | 2.6 | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-2.6, CT2,6-12H, CTG2.6-12H           | 2.6 | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.8                                  | 2.8 | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.8 FR                               | 2.8 | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-2.9                                  | 2.9 | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-2.9 FR                               | 2.9 | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-20                                   | 20  | 12 | - | - | - | - | - | HB  | - | - |
|                                            |     |    |   |   |   |   |   |     |   |   |

|                                                        |     |    |   |   |   |   |   |     |   |   |
|--------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| DJW12-20 FR; LPC12-20 FR, LHR1290W, LHP1295W, LPL12-20 | 20  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-22 FR                                            | 22  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-22, LP12-22, BW12220, ES22-12-X                  | 22  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-24 FR, DJW12-24S FR                              | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-24, DJW12-24S                                    | 24  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-24H                                              | 24  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-24H FR                                           | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-26 FR                                            | 26  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-26, 837-0978                                     | 26  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-26H, LHP12100W                                   | 26  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-28 FR, UPS12-100 FR                              | 28  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-28, UPS12-100                                    | 28  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-28H FR                                           | 28  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-28H, CTG28-12S                                   | 28  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-3.0                                              | 3   | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-3.0 FR                                           | 3   | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-3.2 FR                                           | 3.2 | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-3.2, LP12-3.4, DJW12-3.4, 12LS-3.4, US12-3.4     | 3.2 | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-3.4                                              | 3.4 | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-3.5                                              | 3.5 | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-3.5 FR                                           | 3.5 | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-30                                               | 30  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-33 FR                                            | 33  | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-33, 6-EV-33, LPGS12-33, CTH33-12                 | 33  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-35, ES36-12-X                                    | 35  | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-4.0 FR, LP12-4.0 FR, ELA-12V-4.0AH FR            | 4   | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-4.0, ELA-12V-4.0AH                               | 4   | 12 | - | - | - | - | - | HB  | - | - |
| DJW12-4.0L FR                                          | 4   | 12 | - | - | - | - | - | V-0 | - | - |

|                                                             |     |    |   |   |   |   |   |     |   |   |
|-------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>DJW12-4.0L, LP12-4.0L, CTG4A-12, 698-8091, XV12-4.0L</b> | 4   | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-4.5 FR, DJW12-4.5X FR</b>                          | 4.5 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-4.5, DJW12-4.5X</b>                                | 4.5 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-5.0 FR, LP12-5.5L FR</b>                           | 5   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-5.0, LP12-5.5L</b>                                 | 5   | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-5.0H</b>                                           | 5   | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-5.0H FR</b>                                        | 5   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-5.4</b>                                            | 5.4 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-5.4 FR</b>                                         | 5.4 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-5.5 FR</b>                                         | 5.5 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-5.5, CPS5.5-12</b>                                 | 5.5 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-6.0 FR, CPS7-12 FR, LP12-5.5 FR</b>                | 6   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-6.0, CPS7-12, LP12-5.5, CT6-12</b>                 | 6   | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-7.0 FR, DJW12-7.0EL FR, DJW12-7.0E FR</b>          | 7   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-7.0, DJW12-7.0EL, DJW12-7.0E</b>                   | 7   | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-7.0L</b>                                           | 7   | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-7.0L FR</b>                                        | 7   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-7.2</b>                                            | 7.2 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-7.2 FR</b>                                         | 7.2 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-7.5</b>                                            | 7.5 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-7.5 FR</b>                                         | 7.5 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-7.6 FR</b>                                         | 7.6 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-7.6, N12-7.6T1, N12-7.6T2, LP12-7.6</b>            | 7.6 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-7.8</b>                                            | 7.8 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-8.0 FR, LHR1234W, LHR1236W, LHP1236W, LHP1238W</b> | 8   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>DJW12-8.0, LHR1234W, LHR1236W, BW1280</b>                | 8   | 12 | - | - | - | - | - | HB  | - | - |
| <b>DJW12-8.5, CTG9-12</b>                                   | 8.5 | 12 | - | - | - | - | - | V-0 | - | - |

|                                       |     |    |   |   |   |   |   |     |   |   |
|---------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| DJW12-9.0 FR, LP12-9.0 FR, ES9-12FR-X | 9   | 12 | - | - | - | - | - | V-0 | - | - |
| DJW12-9.0, BW1290                     | 9   | 12 | - | - | - | - | - | HB  | - | - |
| DJW2-4.0                              | 4   | 2  | - | - | - | - | - | HB  | - | - |
| DJW2-4.0 FR                           | 4   | 2  | - | - | - | - | - | V-0 | - | - |
| DJW24-1.3                             | 1.3 | 24 | - | - | - | - | - | HB  | - | - |
| DJW24-1.3 FR                          | 1.3 | 24 | - | - | - | - | - | V-0 | - | - |
| DJW24-3.5                             | 3.5 | 24 | - | - | - | - | - | HB  | - | - |
| DJW24-3.5 FR                          | 3.5 | 24 | - | - | - | - | - | V-0 | - | - |
| DJW24-4.0                             | 4   | 24 | - | - | - | - | - | HB  | - | - |
| DJW24-4.0 FR                          | 4   | 24 | - | - | - | - | - | V-0 | - | - |
| DJW24-4.5                             | 4.5 | 24 | - | - | - | - | - | HB  | - | - |
| DJW24-4.5 FR                          | 4.5 | 24 | - | - | - | - | - | V-0 | - | - |
| DJW4-0.4, LP4-0.4                     | 0.4 | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-0.7, LP4-0.7                     | 0.7 | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-1.2, LP4-1.2                     | 1.2 | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-10                               | 10  | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-10 FR                            | 10  | 4  | - | - | - | - | - | V-0 | - | - |
| DJW4-20                               | 20  | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-20 FR                            | 20  | 4  | - | - | - | - | - | V-0 | - | - |
| DJW4-3.5                              | 3.5 | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-3.5 FR                           | 3.5 | 4  | - | - | - | - | - | V-0 | - | - |
| DJW4-4.0                              | 4   | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-4.0 FR                           | 4   | 4  | - | - | - | - | - | V-0 | - | - |
| DJW4-4.5                              | 4.5 | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-4.5 FR                           | 4.5 | 4  | - | - | - | - | - | V-0 | - | - |
| DJW4-5.0                              | 5   | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-5.0 FR                           | 5   | 4  | - | - | - | - | - | V-0 | - | - |
| DJW4-8.0                              | 8   | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-8.0 FR                           | 8   | 4  | - | - | - | - | - | V-0 | - | - |
| DJW4-9.0                              | 9   | 4  | - | - | - | - | - | HB  | - | - |
| DJW4-9.0 FR                           | 9   | 4  | - | - | - | - | - | V-0 | - | - |
| DJW4-9S                               | 9   | 4  | - | - | - | - | - | HB  | - | - |
| DJW6-0.5                              | 0.5 | 6  | - | - | - | - | - | HB  | - | - |
| DJW6-0.5 FR                           | 0.5 | 6  | - | - | - | - | - | V-0 | - | - |

|              |     |   |   |   |   |   |   |     |   |   |
|--------------|-----|---|---|---|---|---|---|-----|---|---|
| DJW6-0.5 FR  | 0.5 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-1.0     | 1   | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-1.0 FR  | 1   | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-1.2     | 1.2 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-1.2 FR  | 1.2 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-1.4     | 1.4 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-1.4 FR  | 1.4 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-10      | 10  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-10 FR   | 10  | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-10L     | 10  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-10L FR  | 10  | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-10W     | 10  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-10WT    | 10  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-12      | 12  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-12 FR   | 12  | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-13      | 13  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-13 FR   | 13  | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-13FP    | 13  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-13FP FR | 13  | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-14      | 14  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-14 FR   | 14  | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-2.0     | 2   | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-2.0 FR  | 2   | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-2.5     | 2.6 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-2.5 FR  | 2.5 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-2.8     | 2.8 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-2.8 FR  | 2.8 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-2.8H    | 2.8 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-20      | 20  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-20 FR   | 20  | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-3.0     | 3   | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-3.2     | 3.2 | 6 | - | - | - | - | - | HB  | - | - |

|             |     |   |   |   |   |   |   |     |   |   |
|-------------|-----|---|---|---|---|---|---|-----|---|---|
| DJW6-3.2 FR | 3.2 | 6 | - | - | - | - | - | V-0 | - | - |
|-------------|-----|---|---|---|---|---|---|-----|---|---|

|                                       |     |   |   |   |   |   |   |     |   |   |
|---------------------------------------|-----|---|---|---|---|---|---|-----|---|---|
| DJW6-3.2H                             | 3.2 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-36                               | 36  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-36 FR                            | 36  | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-4.0                              | 4   | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-4.0 FR                           | 4   | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-4.0L                             | 4   | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-4.0L FR                          | 4   | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-4.0P                             | 4   | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-4.0W                             | 4   | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-4.5                              | 4.5 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-4.5 FR                           | 4.5 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-4.5S                             | 4.5 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-4.5S FR                          | 4.5 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-42                               | 42  | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-42 FR                            | 42  | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-5.0                              | 5   | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-5.0 FR                           | 5   | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-5.0C                             | 5   | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-5.5                              | 5.5 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-5.5 FR                           | 5.5 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-6.0 FR, LP6-5.0L FR, LP6-5.0T FR | 6   | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-6.0, LP6-5.0T                    | 6   | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-6.0A FR, LP6-5.5 FR              | 5.5 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-6.0A, LP6-5.5                    | 5.5 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-6.5                              | 6.5 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-6.5 FR                           | 6.5 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-6.8                              | 6.8 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-7.0 FR                           | 7.0 | 6 | - | - | - | - | - | V-0 | - | - |
| DJW6-7.0, 6V7AH                       | 7.0 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-7.0L                             | 7.0 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-7.0L FR                          | -   | - | - | - | - | - | - | V-0 | - | - |
| DJW6-7.0W                             | 7.0 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-7.0WT                            | 7.0 | 6 | - | - | - | - | - | HB  | - | - |
| DJW6-7.0                              | 7.0 | 6 | - | - | - | - | - | HB  | - | - |

|                                                            |     |    |   |   |   |   |   |     |   |   |
|------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>DJW6-7.2</b>                                            | 7.2 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJW6-7.2 FR</b>                                         | 7.2 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJW6-7.5</b>                                            | 7.5 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJW6-7.5 FR</b>                                         | 7.5 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJW6-7.8</b>                                            | 7.8 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJW6-7.8 FR</b>                                         | 7.8 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJW6-8.0</b>                                            | 8   | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJW6-8.0 FR</b>                                         | 8   | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJW6-8.0LH</b>                                          | 8   | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJW6-8.0LH FR</b>                                       | 8   | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJW6-8.5</b>                                            | 8.5 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJW6-8.5 FR</b>                                         | 8.5 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJW6-9.0, DJW6-9.0 FR, LP6-9 FR</b>                     | 9   | 6  | - | - | - | - | - | HB  | - | - |
| <b>DJW8-3.2</b>                                            | 3.2 | 8  | - | - | - | - | - | HB  | - | - |
| <b>DJW8-3.2 FR</b>                                         | 3.2 | 8  | - | - | - | - | - | V-0 | - | - |
| <b>DTA12145, LPC12-145, DTA12150</b>                       | 145 | 12 | - | - | - | - | - | HB  | - | - |
| <b>DTA6100, LPC6-100</b>                                   | 100 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DTA6224, LPC6-200H, DTA6210, ED62240, BW EVGC6-220A</b> | 224 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DTA6245, LPC6-220H, DTA6260</b>                         | 245 | 6  | - | - | - | - | - | HB  | - | - |
| <b>DTA8200, LPC8-200, BW EVGC8-170A</b>                    | 200 | 8  | - | - | - | - | - | HB  | - | - |
| <b>ED12140</b>                                             | 12  | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-1.2</b>                                            | 1.2 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-100</b>                                            | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-12</b>                                             | 12  | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-120</b>                                            | 120 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-150</b>                                            | 150 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-18</b>                                             | 18  | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-2.3</b>                                            | 2.3 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-2.6</b>                                            | 2.6 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-2.9</b>                                            | 2.9 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-3.2</b>                                            | 3.2 | 12 | - | - | - | - | - | HB  | - | - |

|                                                      |     |    |   |   |   |   |   |     |   |   |
|------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>EK12-200</b>                                      | 200 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-250</b>                                      | 250 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-26</b>                                       | 26  | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-3.2</b>                                      | 3.2 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-30</b>                                       | 30  | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-33</b>                                       | 33  | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-4.0L</b>                                     | 4   | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-4.5</b>                                      | 4.5 | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-40</b>                                       | 40  | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK12-7.0</b>                                      | 7   | 12 | - | - | - | - | - | HB  | - | - |
| <b>EK6-1.2</b>                                       | 1.2 | 6  | - | - | - | - | - | HB  | - | - |
| <b>EK6-4.5</b>                                       | 4.5 | 6  | - | - | - | - | - | HB  | - | - |
| <b>EV6390</b>                                        | 390 | 6  | - | - | - | - | - | HB  | - | - |
| <b>FT12-100</b>                                      | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-100 FR</b>                                   | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>FT12-100H FR, FT12-100HR FR</b>                   | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>FT12-100H, FT12-100HR, FT12-100, LPFG12-100HS</b> | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-100L</b>                                     | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-125</b>                                      | 125 | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-125 FR</b>                                   | 125 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>FT12-150</b>                                      | 150 | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-150 FR</b>                                   | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>FT12-150L</b>                                     | 150 | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-170</b>                                      | 180 | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-180</b>                                      | 180 | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-180 FR</b>                                   | 180 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>FT12-200</b>                                      | 200 | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-40, LPF12-40, CT12-40FT</b>                  | 40  | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-50 FR, LPF12-50 FR</b>                       | 50  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>FT12-50, LPF12-50</b>                             | 50  | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-55</b>                                       | 55  | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-55 FR</b>                                    | 55  | 12 | - | - | - | - | - | V-0 | - | - |

|                                                |      |    |   |   |   |   |   |     |   |   |
|------------------------------------------------|------|----|---|---|---|---|---|-----|---|---|
| <b>FT12-70</b>                                 | 70   | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-75</b>                                 | 75   | 12 | - | - | - | - | - | HB  | - | - |
| <b>FT12-75 FR</b>                              | 75   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>FT12-90 FR</b>                              | 90   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>FT12-90H, FT12-90, LPF12-90H, CT12-90FT</b> | 90   | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-100</b>                               | 100  | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-100H, FTG12-90 HB</b>                 | 90   | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-100L</b>                              | 100  | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-150</b>                               | 150  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>FTG12-150H</b>                              | 150  | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-150L</b>                              | 150  | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-200</b>                               | 200  | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-50</b>                                | 50   | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-60</b>                                | 60   | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-65</b>                                | 65   | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-75</b>                                | 75   | 12 | - | - | - | - | - | HB  | - | - |
| <b>FTG12-90</b>                                | 90   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>HXP12-540 FR</b>                            | 142  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>Khind6-10</b>                               | 10.0 | 6  | - | - | - | - | - | HB  | - | - |
| <b>Khind6-10 FR</b>                            | 10.0 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>Khind6-4.5</b>                              | 4.5  | 6  | - | - | - | - | - | HB  | - | - |
| <b>Khind6-4.5 FR</b>                           | 4.5  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LC2-1000</b>                                | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LC2-1200</b>                                | 1200 | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LC2-200</b>                                 | 200  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LC2-300</b>                                 | 300  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LC2-400</b>                                 | 400  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LC2-500</b>                                 | 500  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LC2-600</b>                                 | 600  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LC2-800</b>                                 | 800  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LCP12-24</b>                                | 6.5  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LCP12-24 FR</b>                             | 6.5  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LCP12-25</b>                                | 7    | 12 | - | - | - | - | - | HB  | - | - |

|                                                              |     |    |   |   |   |   |   |     |   |   |
|--------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>LCP12-26</b>                                              | 7   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LCP12-26 FR</b>                                           | 7   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LCP12-30 FR</b>                                           | 7   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LCP12-34 FR, LCP12-38 FR</b>                              | 7.5 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LCP12-38</b>                                              | 7.5 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LCP12-38 FR</b>                                           | 7.5 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LCP12-80 FR</b>                                           | 18  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LCP12-90 FR</b>                                           | 20  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LDC12-100</b>                                             | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-105-G27-DT</b>                                      | 108 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-105-G27-T, EP-EV27M-105, RMT12-105-G27-T</b>        | 108 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-115-G31-DT</b>                                      | 118 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-115-G31-T, EP-EV31M-115, BWEV31-115, EKDC12-120</b> | 118 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-120</b>                                             | 120 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-135</b>                                             | 135 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-140</b>                                             | 144 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-145</b>                                             | 148 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-15</b>                                              | 15  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-150-GC12, EKDC12-150</b>                            | 150 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-180</b>                                             | 180 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-200-4D</b>                                          | 200 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-220</b>                                             | 220 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-245</b>                                             | 245 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-25</b>                                              | 25  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-250-8D</b>                                          | 245 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-26</b>                                              | 26  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-285-8D</b>                                          | 285 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-330-8D</b>                                          | 330 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LDC12-39</b>                                              | 39  | 12 | - | - | - | - | - | HB  | - | - |

|                 |    |    |   |   |   |   |   |    |   |   |
|-----------------|----|----|---|---|---|---|---|----|---|---|
| <b>LDC12-40</b> | 40 | 12 | - | - | - | - | - | HB | - | - |
|-----------------|----|----|---|---|---|---|---|----|---|---|

|                                                                     |     |    |   |   |   |   |   |    |   |   |
|---------------------------------------------------------------------|-----|----|---|---|---|---|---|----|---|---|
| <b>LDC12-53</b>                                                     | 53  | 12 | - | - | - | - | - | HB | - | - |
| <b>LDC12-55</b>                                                     | 55  | 12 | - | - | - | - | - | HB | - | - |
| <b>LDC12-63</b>                                                     | 63  | 12 | - | - | - | - | - | HB | - | - |
| <b>LDC12-68</b>                                                     | 68  | 12 | - | - | - | - | - | HB | - | - |
| <b>LDC12-70</b>                                                     | 70  | 12 | - | - | - | - | - | HB | - | - |
| <b>LDC12-76</b>                                                     | 76  | 12 | - | - | - | - | - | HB | - | - |
| <b>LDC12-90-G24-DT, EP-EV24M-90</b>                                 | 90  | 12 | - | - | - | - | - | HB | - | - |
| <b>LDC12-90-G24-T</b>                                               | 90  | 12 | - | - | - | - | - | HB | - | - |
| <b>LDC12-90C</b>                                                    | 90  | 12 | - | - | - | - | - | HB | - | - |
| <b>LDC6-210-GC2, BWEVGC6-210-DT</b>                                 | 210 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-210B</b>                                                    | 210 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-210C</b>                                                    | 210 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-224-GC2, EKDC6-230-GC2, CBEV-GC2-DT</b>                     | 224 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-245, RMT6-245</b>                                           | 245 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-265-GC2</b>                                                 | 268 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-270</b>                                                     | 270 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-275</b>                                                     | 275 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-315</b>                                                     | 315 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-350, EDC6-350</b>                                           | 350 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-370</b>                                                     | 370 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-400-L16, RMT6-400-L16, CBEV-L16-903-DT, BWEVL16-400A-AM</b> | 400 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-400C</b>                                                    | 400 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC6-400D</b>                                                    | 400 | 6  | - | - | - | - | - | HB | - | - |
| <b>LDC8-165-GC8</b>                                                 | 165 | 8  | - | - | - | - | - | HB | - | - |
| <b>LDC8-180-GC8</b>                                                 | 182 | 8  | - | - | - | - | - | HB | - | - |
| <b>LDC8-195</b>                                                     | 195 | 8  | - | - | - | - | - | HB | - | - |
| <b>LDC8-210-GC8H</b>                                                | 210 | 8  | - | - | - | - | - | HB | - | - |
| <b>LHP12620W</b>                                                    | 180 | 12 | - | - | - | - | - | HB | - | - |
| <b>LHP12700W</b>                                                    | 200 | 12 | - | - | - | - | - | HB | - | - |

|                 |     |   |   |   |   |   |   |     |   |   |
|-----------------|-----|---|---|---|---|---|---|-----|---|---|
| <b>LHR1000W</b> | 390 | 2 | - | - | - | - | - | V-0 | - | - |
|-----------------|-----|---|---|---|---|---|---|-----|---|---|

|                                |     |    |   |   |   |   |   |     |   |   |
|--------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| LHR12-110 FR                   | 110 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12-110, USL12-110, BW121100 | 110 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12-120                      | 120 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12-120 FR                   | 120 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12-14                       | 14  | 12 | - | - | - | - | - | HB  | - | - |
| LHR12-14 FR                    | 14  | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12-2.9                      | 2.9 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12-2.9 FR                   | 2.9 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12-22                       | 20  | 12 | - | - | - | - | - | HB  | - | - |
| LHR12-22 FR                    | 20  | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12-28                       | 28  | 12 | - | - | - | - | - | HB  | - | - |
| LHR12-28 FR                    | 28  | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12-37                       | 33  | 12 | - | - | - | - | - | HB  | - | - |
| LHR12-37 FR                    | 33  | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12-45                       | 45  | 12 | - | - | - | - | - | HB  | - | - |
| LHR12-45 FR                    | 45  | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12-6.0                      | 5.4 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12-6.0 FR                   | 5.4 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12-80                       | 60  | 12 | - | - | - | - | - | HB  | - | - |
| LHR12-80 FR                    | 60  | 12 | - | - | - | - | - | V-0 | - | - |
| LHR1200W                       | 400 | 2  | - | - | - | - | - | V-0 | - | - |
| LHR12215W HB                   | 65  | 12 | - | - | - | - | - | HB  | - | - |
| LHR12255W                      | 70  | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12300W                      | 75  | 12 | - | - | - | - | - | V-0 | - | - |
| LHR1230W                       | 7.5 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12330W HB                   | 90  | 12 | - | - | - | - | - | HB  | - | - |
| LHR12350W                      | 85  | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12365W                      | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12365W HB                   | 100 | 12 | - | - | - | - | - | HB  | - | - |
| LHR1236W                       | 8   | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12370W                      | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12390FT                     | 95  | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12390W                      | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12400W HB                   | 100 | 12 | - | - | - | - | - | HB  | - | - |

|                               |     |    |   |   |   |   |   |     |   |   |
|-------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| LHR12400W HB                  | 100 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12420W                     | 110 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12450W                     | 115 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12490W                     | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12500W                     | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR1250W                      | 490 | 2  | - | - | - | - | - | V-0 | - | - |
| LHR12510W                     | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12510W HB                  | 140 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12510W(A)                  | 130 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12520W                     | 155 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12520W HB                  | 155 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12550FT                    | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12550W                     | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12600FT                    | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12600W HB                  | 180 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12605W                     | 170 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12605W(A)                  | 160 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12650W                     | 170 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12690W HB                  | 200 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12700FT                    | 180 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12700W(A)                  | 180 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12705W                     | 190 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12750W                     | 210 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12765W HB                  | 230 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12785W HB,<br>LHR12800W HB | 250 | 12 | - | - | - | - | - | HB  | - | - |
| LHR12800W                     | 205 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12815W                     | 230 | 12 | - | - | - | - | - | V-0 | - | - |
| LHR12820W HB                  | 250 | 12 | - | - | - | - | - | HB  | - | - |
| LHR1500W                      | 580 | 2  | - | - | - | - | - | V-0 | - | - |
| LHR1520W                      | 500 | 2  | - | - | - | - | - | V-0 | - | - |
| LHR1800W                      | 600 | 2  | - | - | - | - | - | V-0 | - | - |
| LHR1950W                      | 650 | 2  | - | - | - | - | - | V-0 | - | - |
| LHR2000W                      | 780 | 2  | - | - | - | - | - | V-0 | - | - |
| LHR1500W                      | 580 | 2  | - | - | - | - | - | V-0 | - | - |

|                                                       |      |    |   |   |   |   |   |     |   |   |
|-------------------------------------------------------|------|----|---|---|---|---|---|-----|---|---|
| LHR2400W                                              | 800  | 2  | - | - | - | - | - | V-0 | - | - |
| LHR2450W                                              | 800  | 2  | - | - | - | - | - | V-0 | - | - |
| LHR2500W                                              | 980  | 2  | - | - | - | - | - | V-0 | - | - |
| LHR2850W                                              | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| LHR500W                                               | 180  | 2  | - | - | - | - | - | V-0 | - | - |
| LHR6-1.4                                              | 1.4  | 6  | - | - | - | - | - | HB  | - | - |
| LHR6-1.4 FR                                           | 1.4  | 6  | - | - | - | - | - | V-0 | - | - |
| LHR6-14                                               | 14   | 6  | - | - | - | - | - | HB  | - | - |
| LHR6-14 FR                                            | 14   | 6  | - | - | - | - | - | V-0 | - | - |
| LHR6-6.0                                              | 6.0  | 6  | - | - | - | - | - | HB  | - | - |
| LHR6-6.0 FR                                           | 6.0  | 6  | - | - | - | - | - | V-0 | - | - |
| LHR600W                                               | 200  | 2  | - | - | - | - | - | V-0 | - | - |
| LHR750W                                               | 300  | 2  | - | - | - | - | - | V-0 | - | - |
| LHR900W                                               | 300  | 2  | - | - | - | - | - | V-0 | - | - |
| LHR950W                                               | 300  | 2  | - | - | - | - | - | V-0 | - | - |
| LHT12-10                                              | 10   | 12 | - | - | - | - | - | V-0 | - | - |
| LHT2-650, DJ650HS,<br>LPL2-650M                       | 650  | 2  | - | - | - | - | - | V-0 | - | - |
| LHTF12-100                                            | 100  | 12 | - | - | - | - | - | V-0 | - | - |
| LHTF12-150                                            | 150  | 12 | - | - | - | - | - | V-0 | - | - |
| LHTF12-200                                            | 200  | 12 | - | - | - | - | - | V-0 | - | - |
| LHTF12-65, LHTF12-80,<br>LHTF12-100, LOP12-90FT<br>FR | 100  | 12 | - | - | - | - | - | V-0 | - | - |
| LMB2-1500                                             | 1500 | 2  | - | - | - | - | - | HB  | - | - |
| LMB2-2000                                             | 2000 | 2  | - | - | - | - | - | HB  | - | - |
| LMB2-3000                                             | 3000 | 2  | - | - | - | - | - | HB  | - | - |
| LOP12-134FR                                           | 134  | 12 | - | - | - | - | - | V-0 | - | - |
| LOP12-135FT-FR                                        | 135  | 12 | - | - | - | - | - | V-0 | - | - |
| LOP12-180FT-FR                                        | 180  | 12 | - | - | - | - | - | V-0 | - | - |
| LOP12-38FR                                            | 38   | 12 | - | - | - | - | - | V-0 | - | - |
| LOP12-40B-FT-FR                                       | 39.4 | 12 | - | - | - | - | - | V-0 | - | - |
| LOP12-40FR                                            | 40   | 12 | - | - | - | - | - | V-0 | - | - |
| LOP12-52                                              | 50   | 12 | - | - | - | - | - | HB  | - | - |
| LOP12-52 FR                                           | 50   | 12 | - | - | - | - | - | HB  | - | - |
| LOP12-52FR                                            | 50   | 12 | - | - | - | - | - | V-0 | - | - |

|                                                                                                                                                                                                                                                                                           |     |    |   |   |   |   |   |     |   |   |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>LOP12-52FR</b>                                                                                                                                                                                                                                                                         | 52  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LOP12-88FR</b>                                                                                                                                                                                                                                                                         | 88  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LOP12-90FT</b>                                                                                                                                                                                                                                                                         | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LOP12-90FT-FR</b>                                                                                                                                                                                                                                                                      | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LOP6-60FR</b>                                                                                                                                                                                                                                                                          | 60  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LP12-0.8 FR, CT0,8-12P FR</b>                                                                                                                                                                                                                                                          | 0.8 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-0.8, CT0,8-12P, CTG0.8-12P</b>                                                                                                                                                                                                                                                    | 0.8 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-1.2 FR, CT1,3-12 FR, ELA-12V1.3AH FR, 150-1558</b>                                                                                                                                                                                                                                | 1.2 | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LP12-1.2, CT1,3-12, ELA-12V1.3AH, ES1213, 12LS-1.2, 537-5444, ES1.2-12-X, SP12-1.2</b>                                                                                                                                                                                                 | 1.2 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-1.3, CTG1.3-12</b>                                                                                                                                                                                                                                                                | 1.3 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-1.30</b>                                                                                                                                                                                                                                                                          | 1.3 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-1.5</b>                                                                                                                                                                                                                                                                           | 1.5 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-1.5 FR</b>                                                                                                                                                                                                                                                                        | 1.5 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-1.9 FR</b>                                                                                                                                                                                                                                                                        | 1.9 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-1.9, ES1223</b>                                                                                                                                                                                                                                                                   | 1.9 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-10 FR</b>                                                                                                                                                                                                                                                                         | 10  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-10, 6-DZM-10, LPE12-10, SP12-10</b>                                                                                                                                                                                                                                               | 10  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-100 FR, CT100-12 FR, LHT12-100, LP12-100E, LHR12360W, LHP12380W</b>                                                                                                                                                                                                               | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-100, DJM12100L, DJM12100H, LP12-100H, U12V380P/B, U12V370P/B, CT100-12, LCP12-360, XVP12-360, ELHR-12V-140AH, ELHR-12V-100AH, XVP12-340, LCP12-340, XV12-100, LHR12335W, U12V360P/B, LLP12-100, EM121200S, ES121000, AXB121000, 727-0398, M100-12 SLD M-X, SP12-100, SP12-110</b> | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-100L, B206, LP12-100C</b>                                                                                                                                                                                                                                                         | 100 | 12 | - | - | - | - | - | HB  | - | - |

|                                                                                                                                                                                                            |     |    |   |   |   |   |   |     |   |   |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| LP12-10H FR, CT10-12S FR, ELA-12V-10AH FR                                                                                                                                                                  | 10  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-10H, CT10-12S, ELA-12V-10AH, ES12100, ED12100, BW12100, MP10-12S, ES10-12S-X                                                                                                                          | 10  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-10S                                                                                                                                                                                                   | 9.4 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-11                                                                                                                                                                                                    | 10  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-110, LP12-110H, LP12-110E                                                                                                                                                                             | 110 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-12 FR, LHR1248W, CT12-12 FR, ELA-12V-12AH FR, 150-1560                                                                                                                                                | 12  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-12, N12-12T2, GX12-12F2, CT12-12, ELA-12V-12AH, 6-DZM-12, XV12-12, ES12120, BW12120, LPE12-12, AXB12120, CTG12-12, CTH12-12, 12LS-12, 537-7305, ES12-12-X, ES12-12SA-X, ES12-12TE-X, KB12-12, SP12-12 | 12  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-120 FR, CT120-12 FR, LHR12480W, LHR12375W                                                                                                                                                             | 120 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-120, CT20-12, XPE12-320, LHTF12-120, ES121200, 12LS-120, 727-0401, KB120-12, SP12-120, CT120-12                                                                                                       | 120 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-135 FR                                                                                                                                                                                                | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-135, N12-135I                                                                                                                                                                                         | 140 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-14 FR, LHR1255W                                                                                                                                                                                       | 14  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-14, ES14-12-X, N12-14T2, CTG14-12                                                                                                                                                                     | 14  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-140 FR                                                                                                                                                                                                | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-140, LPC12-140                                                                                                                                                                                        | 140 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-15 FR                                                                                                                                                                                                 | 15  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-15(A)                                                                                                                                                                                                 | 15  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-15, FM12170C, SP12-15                                                                                                                                                                                 | 15  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-150 FR, CT150-12 FR, LHR12510W,                                                                                                                                                                       | 150 | 12 | - | - | - | - | - | V-0 | - | - |

|                                                                                                                                                                                                                                      |     |    |   |   |   |   |   |     |   |   |
|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| LHP12535W, DJM12150H, LHR12540W                                                                                                                                                                                                      |     |    |   |   |   |   |   |     |   |   |
| LP12-150, DJM12150L, CT150-12, DJM12165S, U12V510P/B, AXB121500, XV12-150, SP12-150                                                                                                                                                  | 150 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-160                                                                                                                                                                                                                             | 160 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-17, LPE12-17, CTG17-12, CTH17-12, 12LS-17, 12LSX-17, CT17-12H                                                                                                                                                                   | 17  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-18 FR, CT17-12 FR, ELA-12V-18AH FR, LHR1270W, 150-1557                                                                                                                                                                          | 18  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-18, N12-18NB, GX12-18NB, U12V75P/B, CT17-12, ELA-12V-18AH, LCP12-80, 6-DZM-17, LCP12-70, XVP12-80, FM12180, XVP12-70, XV12-18, U12V80P/B, ES12220, ES12180, BW12180, 12LS-18, 537-5494, ES17-12-X, ES17-12S-X, KB18-12, SP12-18 | 18  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-180 V0, LPC12-180, XPE12-520, LP12-180 FR, LHR12600W, LHR12602W, LHP12630W, LHR12605W, DJM12180H, U12V600P/B, LHR12620W, BW-4D narrow, AXB121800                                                                                | 180 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-180, LPG12-180S, LPGS12-180, 6-EV-180, ELHR-12V-180AH                                                                                                                                                                           | 180 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-2.0C1 FR                                                                                                                                                                                                                        | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-2.0C1, ES2-12SLM-X                                                                                                                                                                                                              | 2   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-2.0NP                                                                                                                                                                                                                           | 2   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-2.0NP FR                                                                                                                                                                                                                        | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-2.2, DJW12-2.2                                                                                                                                                                                                                  | 2.2 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-2.3 FR, CT2,3-12 FR, ELA-12V-2.2AH FR                                                                                                                                                                                           | 2.3 | 12 | - | - | - | - | - | V-0 | - | - |

|                                                   |     |    |   |   |   |   |   |    |   |   |
|---------------------------------------------------|-----|----|---|---|---|---|---|----|---|---|
| <b>LP12-2.3, CT2,3-12, ELA-12V-2.2AH, ES1223,</b> | 2.3 | 12 | - | - | - | - | - | HB | - | - |
|---------------------------------------------------|-----|----|---|---|---|---|---|----|---|---|

|                                                                                                                                                                                                 |     |    |   |   |   |   |   |     |   |   |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| CTG2.3-12, 537-5450, ES1.9-12-X, ES2.4-12L-X, KB2.3-12, SP12-2.3                                                                                                                                |     |    |   |   |   |   |   |     |   |   |
| LP12-2.3C FR, CT2,3-12C FR                                                                                                                                                                      | 2.3 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-2.3C, CT2,3-12C, XV12-2.3, CT1.8-12C                                                                                                                                                       | 2.3 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-2.5                                                                                                                                                                                        | 2.5 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-2.5 FR                                                                                                                                                                                     | 2.5 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-2.6                                                                                                                                                                                        | 2.6 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-2.6 FR                                                                                                                                                                                     | 2.6 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-2.8 FR                                                                                                                                                                                     | 2.8 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-2.8, ES3-12R-X                                                                                                                                                                             | 2.8 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-2.9 FR, CT2,9-12 FR                                                                                                                                                                        | 2.9 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-2.9, CT2,9-12, CPS3.6-12, ES1233, ES1229, LP12-2.9L, 698-8082, ES2.9-12-X, CTG2.9-12                                                                                                       | 2.9 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-20 FR, LHR1285W, 198-4039, CTG20-12                                                                                                                                                        | 20  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-20, N12-20NB, U12V85P/B, LCP12-90, 6-DZM-20, XVP12-90, U12V90P/B, ES12220, AXB12200, TW12200, 12LH-80W, 727-0391, 727-0405, RMT12-20, ES20-12C FT-X, ES20-12C-X, ES20-12C FT FR-X, SP12-20 | 20  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-200 FR, CT200-12 FR, LHT12-150, LHT12-200, LHR12694W, LHP12730W, LHP12725W, LHR12690W, LHR12700W, DJM12200H, LHR12730W, LHR12740W                                                          | 200 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-200, DJM12200L, CT200-12, LCP12-650, XVP12-650, XP12-740FR, LHT12-200, XV12-200, U12V690P/B, BW-4D-AGM, SP12-200, XP12-740                                                                 | 200 | 12 | - | - | - | - | - | HB  | - | - |

|                           |     |    |   |   |   |   |   |    |   |   |
|---------------------------|-----|----|---|---|---|---|---|----|---|---|
| <b>LP12-230, ES122200</b> | 230 | 12 | - | - | - | - | - | HB | - | - |
|---------------------------|-----|----|---|---|---|---|---|----|---|---|

|                                                                                                                                                                                                            |     |    |   |   |   |   |   |     |   |   |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>LP12-230, LP12-230 V0,<br/>LPC12-220, LP12-230 FR,<br/>LHR12765W, LHP12805W,<br/>DJM12225H, 6-EV-220</b>                                                                                                | 230 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-24 FR, CT25-12 FR,<br/>ELA-12V-24AH FR, 150-<br/>1559</b>                                                                                                                                          | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-24, CT25-12, ELA-<br/>12V-24AH, CTG25-12,<br/>12LS-24, 12LSX-24, 537-<br/>5501, SP12-24</b>                                                                                                        | 24  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-24H</b>                                                                                                                                                                                            | 24  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-24H FR</b>                                                                                                                                                                                         | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-250 FR,<br/>LHR12850W, LHP12895W,<br/>CT250-12, LHP12860W,<br/>LHR12820W,<br/>DJM12250H, LPC12-250<br/>FR, LHR12785W,<br/>LHR12800W</b>                                                            | 250 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-250, US12-250,<br/>XP12-810FR, LPC12-250,<br/>U12V820P/B, BW-8D,<br/>ES122600, ED122600,<br/>LPGS12-250, TW122500,<br/>XP12-810</b>                                                                | 250 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-26 FR, ELA-12V-<br/>26AH FR</b>                                                                                                                                                                    | 26  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-26, N12-26NB, ELA-<br/>12V-26AH, LLP12-26,<br/>BW12260, ES12260,<br/>AXB12260, TW12260,<br/>12LS-26, ES26-12SA-X,<br/>M12260 SLD M-X,<br/>M12260 SLD M S-X,<br/>KB26-12, XV12-26, SP12-<br/>26</b> | 26  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-260</b>                                                                                                                                                                                            | 260 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-27, LP12-27 HB,<br/>LP12-27A</b>                                                                                                                                                                   | 27  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-28 FR, LHR12103W<br/>FR</b>                                                                                                                                                                        | 28  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-28, LHR12103W,<br/>12LSX-28, SP12-28</b>                                                                                                                                                           | 28  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-28H FR, CT28-12S<br/>FR</b>                                                                                                                                                                        | 28  | 12 | - | - | - | - | - | V-0 | - | - |

|                                                             |    |    |   |   |   |   |   |    |   |   |
|-------------------------------------------------------------|----|----|---|---|---|---|---|----|---|---|
| <b>LP12-28H, CT28-12S, 174-<br/>8859, M12260 SLD M T-X,</b> | 28 | 12 | - | - | - | - | - | HB | - | - |
|-------------------------------------------------------------|----|----|---|---|---|---|---|----|---|---|

|                                                                                                                                          |     |    |   |   |   |   |   |     |   |   |
|------------------------------------------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| SP12-28H                                                                                                                                 |     |    |   |   |   |   |   |     |   |   |
| LP12-28L                                                                                                                                 | 28  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-3.0 FR                                                                                                                              | 3   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-3.0, ES3-12-X                                                                                                                       | 3   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-3.2 FR                                                                                                                              | 3.2 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-3.2, CT3,2-12, ELA-12V-3.4AH, ES1233, CTG3.2-12, 537-5472, KB3.2-12, SP12-3.2                                                       | 3.2 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-3.5                                                                                                                                 | 3.5 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-3.5 FR                                                                                                                              | 3.5 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-3.5L                                                                                                                                | 3.5 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-3.5R                                                                                                                                | 3.5 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-3.6                                                                                                                                 | 3.6 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-3.6 FR                                                                                                                              | 3.6 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-30 FR                                                                                                                               | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-30, 6-DZM-24, FM12300                                                                                                               | 24  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-30H FR, ELA-12V-30AH FR, LPC12-27                                                                                                   | 30  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-30H, ELA-12V-30AH, LPL12-30, KB30-12, KB30-12NF, KB30-12NF(KT), KB30-12(E), XV12-30                                                 | 30  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-32                                                                                                                                  | 33  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-32 FR                                                                                                                               | 33  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-33 FR, CT33-12 FR, DJW12-33S FR, ELA-12V-34AH FR                                                                                    | 33  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-33, N12-33DCNB, GX12-33NB, CT33-12, DJW12-33S, ELA-12V-34AH, XV12-33, AXB12330, TW12330, 12LS-33, MU-1 SLD M-33-X, KB33-12, SP12-34 | 33  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-35 FR, ELA-12V-35AH FR                                                                                                              | 33  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-35, ELA-12V-35AH, LP12-35H, 727-0394                                                                                                | 33  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-38 FR, LHR12125W, CT40-12 FR, ELHR-12V-                                                                                             | 38  | 12 | - | - | - | - | - | V-0 | - | - |

|                                                                                                                                                       |     |    |   |   |   |   |   |     |   |   |
|-------------------------------------------------------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| 38AH FR, LHT12-38,<br>LHR12135W, LHP12140W,<br>LHR12120W, DJM1238H,<br>198-4040                                                                       |     |    |   |   |   |   |   |     |   |   |
| LP12-38, CT40-12, ELHR-<br>12V-38AH, 6-DZM-34,<br>U12V120P/B, AXB12380,<br>TW12380, 12LS-38, 537-<br>5517, SP12-36                                    | 38  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-4.0                                                                                                                                              | 4   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-4.0 FR                                                                                                                                           | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-4.0 FR, ELA-12V-<br>4.0AH FR                                                                                                                     | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-4.0, ELA-12V-4.0AH                                                                                                                               | 2   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-4.0L FR, CT4A-12 FR                                                                                                                              | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-4.0L, LPL12-4.5L,<br>CT4A-12, KB4-12D                                                                                                            | 2   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-4.5 FR, ELA-12V-<br>4.5AH FR                                                                                                                     | 4.5 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-4.5, ELA-12V-4.5AH,<br>XV12-4.5, ES1250, LPE12-<br>4.0, MP4.5-12, KB4.5-12,<br>CTG4.5-12                                                         | 4.5 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-40 FR, LP12-40PC<br>FR, LOP12-40 FR, LOP12-<br>40                                                                                                | 40  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-40 PC                                                                                                                                            | 40  | 12 | - | - | - | - | - | V-2 | - | - |
| LP12-40, XV12-40,<br>DJM1240L, KB40-12NF,<br>KB40-12NF(KT), SP12-40                                                                                   | 40  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-42, LOP12-38,<br>LOP12-38 FR                                                                                                                     | 38  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-45 FR, LHR12160W,<br>CT45-12 FR, ELHR-12V-<br>42AH FR, LHR12153W,<br>LHP12160W, DJM1245H                                                         | 45  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-45, U12V145P/B,<br>CT45-12, ELHR-12V-<br>42AH, U12V160P/B,<br>USL12-42, LLP12-45,<br>BW12500, ES12450, 12LS-<br>45, M45-12 SLD M-X,<br>XVC50-12D | 45  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-45H                                                                                                                                              | 50  | 12 | - | - | - | - | - | HB  | - | - |
|                                                                                                                                                       |     |    |   |   |   |   |   |     |   |   |
| LP12-5.0 FR                                                                                                                                           | 5.0 | 12 | - | - | - | - | - | V-0 | - | - |
|                                                                                                                                                       |     |    |   |   |   |   |   |     |   |   |

|                                                                                                                                                            |     |    |   |   |   |   |   |     |   |   |
|------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| LP12-5.0, 686-7253, ES5-12-X, ES5-12 T2-X, SP12-5                                                                                                          | 5.0 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-5.0H                                                                                                                                                  | 5.0 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-5.0H FR                                                                                                                                               | 5.0 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-5.0S                                                                                                                                                  | 6.0 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-5.0T, BW1250, LPE12-5.0, CTG5-12H, ES5-12SA-X, N12-5.0T1, GX12-5.0F1                                                                                  | 5   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-5.4 FR                                                                                                                                                | 5.4 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-5.4, LP12-5.4H, ES1250, 174-8857, MP5.4-12                                                                                                            | 5.4 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-50 FR                                                                                                                                                 | 50  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-50, DJM1250L, 6-EV-50B, AXB12500, TW12500, ELHR-12V-50AH, M50-12 SLD M-X, SP12-50                                                                     | 50  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-55 FR, LHR12185W, CT55-12 FR, ELHR-12V-55AH FR, LHR12187W, LHP12195W, LHP12225W, DJM1255H                                                             | 55  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-55, U12V180P/B, CT55-12, ELHR-12V-55AH, U12V185P/B, BW12550DC-IT, ES12550, AXB12550, TW12550, 727-0408, M55-12 SLD M-X, XVC62-12D, SP12-55, LPGS12-55 | 55  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-6.0 FR                                                                                                                                                | 6   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-6.0, DJW12-5.5H                                                                                                                                       | 6   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-6.0H                                                                                                                                                  | 6   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-6.0H FR                                                                                                                                               | 6   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-6.0L FR                                                                                                                                               | 6   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-6.0L, N12-6.0T1, N12-6.0T2                                                                                                                            | 6   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-6.0W, CPS7-12                                                                                                                                         | 6   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-6.5, DJW12-6.5, LP12-6.5ST                                                                                                                            | 6.5 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-6.5S                                                                                                                                                  | 6.5 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-6.5FR                                                                                                                                                 | 6.5 | 12 | - | - | - | - | - | V-0 | - | - |

|                                                                                                                                                                                                                                   |     |    |   |   |   |   |   |     |   |   |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>LP12-60 FR</b>                                                                                                                                                                                                                 | 60  | 12 | - | - | - | - | - | V-U | - | - |
| <b>LP12-60, DJM1260L, LPG12-60S, ED12600</b>                                                                                                                                                                                      | 60  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-60T, LP12-60(GROUP 34)</b>                                                                                                                                                                                                | 60  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-65 FR, ELHR-12V65AH FR, LHT12-65, LHR12225W, LHP12235W, LHR12215W, DJM1265H, 174-8860</b>                                                                                                                                 | 65  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-65, U12V215P/B, ELHR-12V65AH, DJM1270S, LHR12210W, U12V210P/B, AXB12650, TW12650, 12LS-65, 537-5539, SP12-65</b>                                                                                                          | 65  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-65L</b>                                                                                                                                                                                                                   | 65  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-65T</b>                                                                                                                                                                                                                   | 65  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-65T FR</b>                                                                                                                                                                                                                | 65  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-7.0 FR, ELA-12V-7.0AH FR, 6-DZM-6, LHR1230W, LHP1232W, LP12-7.0M FR, 150-1556</b>                                                                                                                                         | 7   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-7.0, N12-7.0T1, GX12-7.0F1, LHT12-7.0, ELA-12V-7.0AH, LCP12-30, XVP12-30, DJW12-7, XV12-7.0, STK12-7.0, LHR1230W, LP12-7.0M, ES1275, BW1270, ES1272, LPE12-7.0, AXB1270, 537-5488, ES7-12SA-X, KB7-12, SP12-7, CT7-12</b> | 7   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-7.0E</b>                                                                                                                                                                                                                  | 6   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-7.0L</b>                                                                                                                                                                                                                  | 7   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-7.0L FR</b>                                                                                                                                                                                                               | 7   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-7.2 FR, CT7,2-12 FR, ELA-12V-7.2AH FR</b>                                                                                                                                                                                 | 7.2 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LP12-7.2, CT7,2-12, ELA-12V-7.2AH, CTG7.2-12, 12LS-7.2, ES7-12-X, ES7-12 T2-X, ES7-12FR-X, ES7-12FR T2-X</b>                                                                                                                   | 7.2 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LP12-7.5 FR</b>                                                                                                                                                                                                                | 7.5 | 12 | - | - | - | - | - | V-0 | - | - |

|                                             |     |    |   |   |   |   |   |    |   |   |
|---------------------------------------------|-----|----|---|---|---|---|---|----|---|---|
| <b>LP12-7.5, LCP12-34, XVP12-34, FM1275</b> | 7.5 | 12 | - | - | - | - | - | HB | - | - |
|---------------------------------------------|-----|----|---|---|---|---|---|----|---|---|

|                                                                                                         |     |    |   |   |   |   |   |     |   |   |
|---------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| LP12-7.8                                                                                                | 7.8 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-7.8 FR                                                                                             | 7.8 | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-70 FR, CT70-12 FR, DJM1270H                                                                        | 70  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-70, CT70-12, U12V255P/B                                                                            | 70  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-75 FR, ELHR-12V-75AH FR                                                                            | 75  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-75, U12V245P/B, ELHR-12V-75AH, U12V300P/B, BW12750, 174-8861, SP12-75                              | 75  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-75H FR                                                                                             | 75  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-75H, BW EV-24, M75-12 SLD M-X                                                                      | 75  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-8.0, LHR1235W, CTG8-12H, 198-4037, UCP12-38                                                        | 8   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-8.5 FR, CT9-12 FR, LHR1238W                                                                        | 8   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-8.5, CT9-12, LHR1238W, ES1290                                                                      | 8   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-80 FR, LHR12300W, LHP12315W, LHR12315W, LHR12257W FR                                               | 80  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-80, DJM1280L, U12V280P/B, LCP12-280, LCP12-300, XVP12-280, XVP12-300, LHR12257W, ES12850, 122-4863 | 80  | 12 | - | - | - | - | - | HB  | - | - |
| LP12-9.0 FR                                                                                             | 9   | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-9.0, 12LH-36W, 174-8858, ES9-12-X, ES9-12TE-X, KB9-12, EK12-9, SP12-9, N12-9.0T2                   | 9   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-9.5                                                                                                | 9.5 | 12 | - | - | - | - | - | HB  | - | - |
| LP12-90 FR                                                                                              | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| LP12-90, LCP12-330Z, XVP12-330Z, SP12-90                                                                | 90  | 12 | - | - | - | - | - | HB  | - | - |

|                                    |    |    |   |   |   |   |   |     |   |   |
|------------------------------------|----|----|---|---|---|---|---|-----|---|---|
| LP12-90H FR, LHR12350W, LHP12370W, | 90 | 12 | - | - | - | - | - | V-0 | - | - |
|------------------------------------|----|----|---|---|---|---|---|-----|---|---|

|                                                                                                                          |      |    |   |   |   |   |   |     |   |   |
|--------------------------------------------------------------------------------------------------------------------------|------|----|---|---|---|---|---|-----|---|---|
| LOP12-88, LOP12-88 FR, DJM1285H                                                                                          |      |    |   |   |   |   |   |     |   |   |
| LP12-90H, DJM1290L, U12V320P/B, LCP12-330, LCP12-350, XVP12-330, XVP12-350, EM121000B, LPL12-90, ELHR-12V-90AH, 174-8862 | 90   | 12 | - | - | - | - | - | HB  | - | - |
| LP12-9LS, LP12-9.0SL                                                                                                     | 9    | 12 | - | - | - | - | - | HB  | - | - |
| LP12-9S                                                                                                                  | 9    | 12 | - | - | - | - | - | HB  | - | - |
| LP2-100 FR                                                                                                               | 100  | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-100, US2-100, EK2-100, EKL2-100                                                                                      | 100  | 2  | - | - | - | - | - | HB  | - | - |
| LP2-1000 FR, LHT2-1000, LHR2900W, LHP2950W, LHR2770W                                                                     | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-1000, US2-1000                                                                                                       | 1000 | 2  | - | - | - | - | - | HB  | - | - |
| LP2-120                                                                                                                  | 130  | 2  | - | - | - | - | - | HB  | - | - |
| LP2-120 FR                                                                                                               | 130  | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-1200 FR, LHT2-1200                                                                                                   | 1200 | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-1200, US2-1200                                                                                                       | 1200 | 2  | - | - | - | - | - | HB  | - | - |
| LP2-1250, LP2-1250 V0                                                                                                    | 1250 | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-130                                                                                                                  | 130  | 2  | - | - | - | - | - | HB  | - | - |
| LP2-130 FR                                                                                                               | 130  | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-150 FR                                                                                                               | 150  | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-150, US2-150, MSB-150, EKL2-150                                                                                      | 150  | 2  | - | - | - | - | - | HB  | - | - |
| LP2-1500 FR, LHT2-1500                                                                                                   | 1500 | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-1500, DJ1600, US2-1500                                                                                               | 1500 | 2  | - | - | - | - | - | HB  | - | - |
| LP2-1750, LP2-1750 V0                                                                                                    | 1750 | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-1800                                                                                                                 | 1800 | 2  | - | - | - | - | - | HB  | - | - |
| LP2-1800 FR                                                                                                              | 1800 | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-200 FR, LHR593W, LHP600W, LHR595W, LHR590W, DJ200H                                                                   | 200  | 2  | - | - | - | - | - | V-0 | - | - |
| LP2-200, LHT2-200, US2-200, XV2-200, MSB-200, N2-200DCI                                                                  | 200  | 2  | - | - | - | - | - | HB  | - | - |
| LP2-2000 FR, LHT2-2000                                                                                                   | 2000 | 2  | - | - | - | - | - | V-0 | - | - |
|                                                                                                                          |      |    |   |   |   |   |   |     |   |   |

|                                                                             |      |   |   |   |   |   |   |     |   |   |
|-----------------------------------------------------------------------------|------|---|---|---|---|---|---|-----|---|---|
| <b>LP2-2000, US2-2000</b>                                                   | 2000 | 2 | - | - | - | - | - | HB  | - | - |
| <b>LP2-250 FR</b>                                                           | 250  | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-250, US2-250, XV2-250</b>                                            | 250  | 2 | - | - | - | - | - | HB  | - | - |
| <b>LP2-2500 FR</b>                                                          | 2500 | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-2500, US2-2500</b>                                                   | 2500 | 2 | - | - | - | - | - | HB  | - | - |
| <b>LP2-265H, LP2-265H V0</b>                                                | 265  | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-300 FR, LHT2-300, LHR857W, LHP870W, LHR860W, DJ300H</b>              | 300  | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-300, US2-300, MSBS-300</b>                                           | 300  | 2 | - | - | - | - | - | HB  | - | - |
| <b>LP2-3000 FR</b>                                                          | 3000 | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-3000, US2-3000, LHT2-3000</b>                                        | 3000 | 2 | - | - | - | - | - | HB  | - | - |
| <b>LP2-300I, LP2-300I V0, HW2-300</b>                                       | 300  | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-350 FR</b>                                                           | 350  | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-350, US2-350</b>                                                     | 350  | 2 | - | - | - | - | - | HB  | - | - |
| <b>LP2-3500</b>                                                             | 3500 | 2 | - | - | - | - | - | HB  | - | - |
| <b>LP2-3500 FR</b>                                                          | 3500 | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-4.0</b>                                                              | 4    | 2 | - | - | - | - | - | HB  | - | - |
| <b>LP2-4.0 FR</b>                                                           | 4    | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-400 FR, LHT2-400, LHR1186W, LHP1200W, LHR1190W, LHR1170W, DJ400H</b> | 400  | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-400, US2-400, XVL2-400, MSB-400</b>                                  | 400  | 2 | - | - | - | - | - | HB  | - | - |
| <b>LP2-450</b>                                                              | 450  | 2 | - | - | - | - | - | HB  | - | - |
| <b>LP2-450 FR</b>                                                           | 450  | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-50, LP2-50 V0</b>                                                    | 50   | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-500 FR, LHT2-500, LHR1450W, LHP1470W, LHR1440W, DJ500H, DJ500HS</b>  | 500  | 2 | - | - | - | - | - | V-0 | - | - |
| <b>LP2-500, US2-500</b>                                                     | 500  | 2 | - | - | - | - | - | HB  | - | - |

|                                                  |     |   |   |   |   |   |   |     |   |   |
|--------------------------------------------------|-----|---|---|---|---|---|---|-----|---|---|
| <b>LP2-600 FR, LHT2-600, LHR1714W, LHP1730W,</b> | 600 | 2 | - | - | - | - | - | V-0 | - | - |
|--------------------------------------------------|-----|---|---|---|---|---|---|-----|---|---|

|                                                                     |     |    |   |   |   |   |   |     |   |   |  |
|---------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|--|
| LHR1715W, LHR1710W, DJ600H                                          |     |    |   |   |   |   |   |     |   |   |  |
| LP2-600, US2-600                                                    | 600 | 2  | - | - | - | - | - | HB  | - | - |  |
| LP2-600H, LP2-600H V0                                               | 600 | 2  | - | - | - | - | - | V-0 | - | - |  |
| LP2-600S, LP2-600S V0, HW2-600, LPL2-650M                           | 600 | 2  | - | - | - | - | - | V-0 | - | - |  |
| LP2-65                                                              | 65  | 2  | - | - | - | - | - | HB  | - | - |  |
| LP2-65 FR                                                           | 65  | 2  | - | - | - | - | - | V-0 | - | - |  |
| LP2-700 FR                                                          | 700 | 2  | - | - | - | - | - | V-0 | - | - |  |
| LP2-700, US2-700, EK2-700, MSB-700                                  | 700 | 2  | - | - | - | - | - | HB  | - | - |  |
| LP2-72                                                              | 75  | 2  | - | - | - | - | - | HB  | - | - |  |
| LP2-72 FR                                                           | 75  | 2  | - | - | - | - | - | V-0 | - | - |  |
| LP2-750, LP2-750 V0                                                 | 75  | 2  | - | - | - | - | - | V-0 | - | - |  |
| LP2-750H, LP2-750H V0                                               | 75  | 2  | - | - | - | - | - | V-0 | - | - |  |
| LP2-800 FR, LHT2-800, LHR2372W, LHP2400W, LHR2375W, DJ800H, DJ800HS | 800 | 2  | - | - | - | - | - | V-0 | - | - |  |
| LP2-800, US2-800                                                    | 800 | 2  | - | - | - | - | - | HB  | - | - |  |
| LP2-900                                                             | 900 | 2  | - | - | - | - | - | HB  | - | - |  |
| LP2-900 FR                                                          | 900 | 2  | - | - | - | - | - | V-0 | - | - |  |
| LP24-1.3                                                            | 1.3 | 24 | - | - | - | - | - | HB  | - | - |  |
| LP24-1.3 FR                                                         | 1.3 | 24 | - | - | - | - | - | V-0 | - | - |  |
| LP24-3.5                                                            | 3.5 | 24 | - | - | - | - | - | HB  | - | - |  |
| LP24-3.5 FR                                                         | 3.5 | 24 | - | - | - | - | - | V-0 | - | - |  |
| LP24-4.0                                                            | 4   | 24 | - | - | - | - | - | HB  | - | - |  |
| LP24-4.0 FR                                                         | 4   | 24 | - | - | - | - | - | V-0 | - | - |  |
| LP24-4.5                                                            | 4.5 | 24 | - | - | - | - | - | HB  | - | - |  |
| LP24-4.5 FR                                                         | 4.5 | 24 | - | - | - | - | - | V-0 | - | - |  |
| LP4-10                                                              | 10  | 4  | - | - | - | - | - | HB  | - | - |  |
| LP4-10 FR                                                           | 10  | 4  | - | - | - | - | - | V-0 | - | - |  |
| LP4-20                                                              | 20  | 4  | - | - | - | - | - | HB  | - | - |  |
| LP4-20 FR                                                           | 20  | 4  | - | - | - | - | - | V-0 | - | - |  |
| LP4-3.5 FR                                                          | 3.5 | 4  | - | - | - | - | - | V-0 | - | - |  |
| LP4-3.5, MP3.5-4                                                    | 3.5 | 4  | - | - | - | - | - | HB  | - | - |  |
| LP4-4.0                                                             | 4   | 4  | - | - | - | - | - | HB  | - | - |  |

|                                                                                                                        |     |   |   |   |   |   |   |     |   |   |
|------------------------------------------------------------------------------------------------------------------------|-----|---|---|---|---|---|---|-----|---|---|
| <b>LP4-4.0</b>                                                                                                         | 4   | 4 | - | - | - | - | - | HB  | - | - |
| <b>LP4-4.0 FR</b>                                                                                                      | 4   | 4 | - | - | - | - | - | V-0 | - | - |
| <b>LP4-4.5</b>                                                                                                         | 4.5 | 4 | - | - | - | - | - | HB  | - | - |
| <b>LP4-4.5 FR</b>                                                                                                      | 4.5 | 4 | - | - | - | - | - | V-0 | - | - |
| <b>LP4-5.0</b>                                                                                                         | 5.0 | 4 | - | - | - | - | - | HB  | - | - |
| <b>LP4-5.0 FR</b>                                                                                                      | 5.0 | 4 | - | - | - | - | - | V-0 | - | - |
| <b>LP4-8.0</b>                                                                                                         | 8   | 4 | - | - | - | - | - | HB  | - | - |
| <b>LP4-8.0 FR</b>                                                                                                      | 8   | 4 | - | - | - | - | - | V-0 | - | - |
| <b>LP4-9.0 FR</b>                                                                                                      | 9.0 | 4 | - | - | - | - | - | V-0 | - | - |
| <b>LP4-9.0, ES9-4-X</b>                                                                                                | 9.0 | 4 | - | - | - | - | - | HB  | - | - |
| <b>LP6-0.5</b>                                                                                                         | 0.5 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-0.5 FR</b>                                                                                                      | 0.5 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-1.0 FR</b>                                                                                                      | 1   | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-1.0, 174-8855</b>                                                                                               | 1   | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-1.2 FR, CT1,3-6 FR, ELA-6V-1.3AH FR</b>                                                                         | 1.2 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-1.2, CT1,3-6, ELA-6V-1.3AH, ES613, CTG1.3-6, 727-0388, MP1.2-6, ES1.2-6-X</b>                                   | 1.2 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-1.4</b>                                                                                                         | 1.4 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-1.4 FR</b>                                                                                                      | 1.4 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-10 FR</b>                                                                                                       | 10  | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-10, ES6120, LPE6-10, 537-5438</b>                                                                               | 10  | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-100</b>                                                                                                         | 100 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-100 FR</b>                                                                                                      | 100 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-10L</b>                                                                                                         | 10  | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-10L FR</b>                                                                                                      | 10  | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-12 FR, CT12-6 FR, ELA-6V-12AH FR, 174-8856</b>                                                                  | 12  | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-12, CT12-6, ELA-6V-12AH, LPE6-12, CTG12-6, 6LS-12, MP12-6, ES12-6-X, ES12-6 T2-X, KB12-6, N6-12T1, GX6-12F1</b> | 12  | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-120</b>                                                                                                         | 120 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-120 FR</b>                                                                                                      | 120 | 6 | - | - | - | - | - | V-0 | - | - |

|                                                                             |     |   |   |   |   |   |   |     |   |   |
|-----------------------------------------------------------------------------|-----|---|---|---|---|---|---|-----|---|---|
| LP6-120 FR                                                                  | 120 | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-13 FR                                                                   | 13  | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-13, ES13-6-X                                                            | 13  | 6 | - | - | - | - | - | HB  | - | - |
| LP6-13FP                                                                    | 13  | 6 | - | - | - | - | - | HB  | - | - |
| LP6-13FP FR                                                                 | 13  | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-14                                                                      | 14  | 6 | - | - | - | - | - | HB  | - | - |
| LP6-14 FR                                                                   | 14  | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-150                                                                     | 150 | 6 | - | - | - | - | - | HB  | - | - |
| LP6-150 FR                                                                  | 150 | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-2.0                                                                     | 2   | 6 | - | - | - | - | - | HB  | - | - |
| LP6-2.0 FR                                                                  | 2   | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-2.5                                                                     | 2.5 | 6 | - | - | - | - | - | HB  | - | - |
| LP6-2.5 FR                                                                  | 2.5 | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-2.8                                                                     | 2.8 | 6 | - | - | - | - | - | HB  | - | - |
| LP6-2.8 FR                                                                  | 2.8 | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-20 FR, ELA-6V-20AH FR                                                   | 20  | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-20, ELA-6V-20AH                                                         | 20  | 6 | - | - | - | - | - | HB  | - | - |
| LP6-200                                                                     | 200 | 6 | - | - | - | - | - | HB  | - | - |
| LP6-200 FR                                                                  | 200 | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-200H                                                                    | 200 | 6 | - | - | - | - | - | HB  | - | - |
| LP6-200H FR                                                                 | 200 | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-3.2 FR                                                                  | 3.2 | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-3.2, LP6-3.7, CT3,2-6, ELA-6V-3.4AH, ES633, CTG3.2-6, 727-0385, ES3-6-X | 3.2 | 6 | - | - | - | - | - | HB  | - | - |
| LP6-3.2H                                                                    | 3.2 | 6 | - | - | - | - | - | HB  | - | - |
| LP6-3.2H FR                                                                 | 3.2 | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-3.2S                                                                    | 3.2 | 6 | - | - | - | - | - | HB  | - | - |
| LP6-3.7                                                                     | 3.7 | 6 | - | - | - | - | - | HB  | - | - |
| LP6-36 FR, ELHR-6V-36AH FR                                                  | 36  | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-36, ELHR-6V-36AH, SP6-36                                                | 36  | 6 | - | - | - | - | - | HB  | - | - |
| LP6-4.0 FR, LP6-4.0H FR                                                     | 4   | 6 | - | - | - | - | - | V-0 | - | - |
| LP6-4.0, LP6-4.0H, LP6-4.0H FR                                              | 4   | 6 | - | - | - | - | - | HB  | - | - |

|                                                                                                                                                        |     |   |   |   |   |   |   |     |   |   |
|--------------------------------------------------------------------------------------------------------------------------------------------------------|-----|---|---|---|---|---|---|-----|---|---|
| <b>LP6-4.0, DJW6-4A, LPE6-4.0, 537-5422, ES4-6SA-X, ES3.8-6-X</b>                                                                                      | 4   | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-4.0L</b>                                                                                                                                        | 4   | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-4.0L FR</b>                                                                                                                                     | 4   | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-4.5 FR, CT4,5-6 FR, LP6-4.5H FR, LP6-4.0H FR, ELA-6V-4.5AH FR</b>                                                                               | 4.5 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-4.5, N6-4.5T1, GX6-4.5F1, XV6-4.5, CT4,5-6, LP6-4.5H, LP6-4.0H, ELA-6V-4.5AH, LPE6-4.5, BW645, CTG4.5-6, MP4.5-6, ES4-6-X, KB4.5-6, SP6-4.5</b> | 4.5 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-4.5S</b>                                                                                                                                        | 4.5 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-4.5S FR</b>                                                                                                                                     | 4.5 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-42</b>                                                                                                                                          | 42  | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-42 FR</b>                                                                                                                                       | 42  | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-5.0</b>                                                                                                                                         | 5.0 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-5.0 FR</b>                                                                                                                                      | 5.0 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-5.0H</b>                                                                                                                                        | 5.0 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-5.0H FR</b>                                                                                                                                     | 5.0 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-5.0S</b>                                                                                                                                        | 4.5 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-5.0S FR</b>                                                                                                                                     | 4.5 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-5.4 FR, ELA-6V-5.0AH FR</b>                                                                                                                     | 6.0 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-5.4, ELA-6V-5.0AH, LP6-5.0, ES650A</b>                                                                                                          | 6.0 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-6.0 FR</b>                                                                                                                                      | 6.0 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-6.0, BW650, LP6-5.0L</b>                                                                                                                        | 6.0 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-6.0C</b>                                                                                                                                        | 6.0 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-6.5</b>                                                                                                                                         | 6.5 | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-6.5 FR</b>                                                                                                                                      | 6.5 | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-60 FR</b>                                                                                                                                       | 60  | 6 | - | - | - | - | - | V-0 | - | - |
| <b>LP6-60 PC</b>                                                                                                                                       | 60  | 6 | - | - | - | - | - | V-2 | - | - |
| <b>LP6-60, LOP6-60, LOP6-60 FR</b>                                                                                                                     | 60  | 6 | - | - | - | - | - | HB  | - | - |
| <b>LP6-7.0 FR, CT7-6 FR, DJW6-7, DJW6-5, EK6-7.0</b>                                                                                                   | 7   | 6 | - | - | - | - | - | V-0 | - | - |

| FR                                                                                |     |    |   |   |   |   |   |     |   |   |
|-----------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| LP6-7.0, CT7-6, ES670, LPE6-7.0, CTG7-6, 727-0382, MP7-6, ES7-6-X, KB7-6, EK6-7.0 | 7   | 6  | - | - | - | - | - | HB  | - | - |
| LP6-7.0L FR, ELA-6V-7.0AH FR                                                      | 7   | 6  | - | - | - | - | - | V-0 | - | - |
| LP6-7.0L, ELA-6V-7.0AH                                                            | 7   | 6  | - | - | - | - | - | HB  | - | - |
| LP6-7.2 FR, ELA-6V-7.2AH FR                                                       | 7.2 | 6  | - | - | - | - | - | V-0 | - | - |
| LP6-7.2, ELA-6V-7.2AH, LPE6-7.2, N6-7.2T1, GX6-7.2F1                              | 7.2 | 6  | - | - | - | - | - | HB  | - | - |
| LP6-7.5                                                                           | 7.5 | 6  | - | - | - | - | - | HB  | - | - |
| LP6-7.5 FR                                                                        | 7.5 | 6  | - | - | - | - | - | V-0 | - | - |
| LP6-7.8 FR                                                                        | 7.8 | 6  | - | - | - | - | - | V-0 | - | - |
| LP6-7.8, LPX6-7                                                                   | 7.8 | 6  | - | - | - | - | - | HB  | - | - |
| LP6-8.5 FR                                                                        | 8.5 | 6  | - | - | - | - | - | V-0 | - | - |
| LP6-8.5, ES8.2-6S-X                                                               | 8.5 | 6  | - | - | - | - | - | HB  | - | - |
| LP6-8.5H FR, ELA-6V-8.5AH FR                                                      | 8.5 | 6  | - | - | - | - | - | V-0 | - | - |
| LP6-8.5H, ELA-6V-8.5AH                                                            | 8.5 | 6  | - | - | - | - | - | HB  | - | - |
| LP6-8.5L FR                                                                       | 8.5 | 6  | - | - | - | - | - | V-0 | - | - |
| LP6-8.5L, LP6-8.0S                                                                | 8.5 | 6  | - | - | - | - | - | HB  | - | - |
| LP8-3.2                                                                           | 3.2 | 8  | - | - | - | - | - | HB  | - | - |
| LP8-3.2 FR                                                                        | 3.2 | 8  | - | - | - | - | - | V-0 | - | - |
| LPC12-100 FR                                                                      | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| LPC12-100, EV12115, LPC12-100H, DC12-100, DC12-120, 727-0427                      | 100 | 12 | - | - | - | - | - | HB  | - | - |
| LPC12-10H                                                                         | 10  | 12 | - | - | - | - | - | HB  | - | - |
| LPC12-12                                                                          | 12  | 12 | - | - | - | - | - | HB  | - | - |
| LPC12-120 FR                                                                      | 120 | 12 | - | - | - | - | - | V-0 | - | - |
| LPC12-120, LPF12-160, DC12-120, 727-0433                                          | 120 | 12 | - | - | - | - | - | HB  | - | - |
| LPC12-13 FR                                                                       | 14  | 12 | - | - | - | - | - | V-0 | - | - |

|                             |    |    |   |   |   |   |   |    |   |   |
|-----------------------------|----|----|---|---|---|---|---|----|---|---|
| LPC12-13, ED12120, 727-0417 | 14 | 12 | - | - | - | - | - | HB | - | - |
|-----------------------------|----|----|---|---|---|---|---|----|---|---|

|                                               |     |    |   |   |   |   |   |     |   |   |
|-----------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>LPC12-150</b>                              | 150 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-150 FR</b>                           | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-150, ED121600, 727-0442</b>          | 150 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-18</b>                               | 20  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-18 FR</b>                            | 20  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-20, ED12200</b>                      | 20  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-200</b>                              | 200 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-200 FR</b>                           | 200 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-24</b>                               | 26  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-24 FR</b>                            | 26  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-24H</b>                              | 28  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-26, LPC12-26H, ED12260</b>           | 26  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-26L</b>                              | 26  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-3.5</b>                              | 3.5 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-3.5 FR</b>                           | 3.5 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-33 FR</b>                            | 33  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-33, LPC12-33S, ED12350, 727-0420</b> | 33  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-38 FR</b>                            | 38  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-38, 727-0423</b>                     | 38  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-42, 122-4862</b>                     | 42  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-45</b>                               | 45  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-5.6</b>                              | 5.4 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-5.6 FR</b>                           | 5.4 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-50</b>                               | 50  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-50 FR</b>                            | 50  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-55 FR</b>                            | 55  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-55, BW EV-22, ED12550, 727-0436</b>  | 55  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-65</b>                               | 65  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-7.2 FR</b>                           | 7.2 | 12 | - | - | - | - | - | V-0 | - | - |

|                          |     |    |   |   |   |   |   |    |   |   |
|--------------------------|-----|----|---|---|---|---|---|----|---|---|
| <b>LPC12-7.2, ED1270</b> | 7.2 | 12 | - | - | - | - | - | HB | - | - |
|--------------------------|-----|----|---|---|---|---|---|----|---|---|

|                                                        |     |    |   |   |   |   |   |     |   |   |
|--------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>LPC12-75</b>                                        | 75  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-75 FR</b>                                     | 75  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-75, 727-0439</b>                              | 75  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-8.0 FR</b>                                    | 8.0 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-8.0, ED1290</b>                               | 8.0 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPC12-80, EV1285, ED12850</b>                       | 80  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC12-90, EV12105, DC12-100</b>                     | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPC6-13</b>                                         | 14  | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPC6-13 FR</b>                                      | 14  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPC6-5.6</b>                                        | 6   | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPC6-5.6 FR</b>                                     | 6   | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPCG12-100</b>                                      | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPCG12-30</b>                                       | 30  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPCG12-55</b>                                       | 55  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPCG12-60</b>                                       | 60  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPCG12-65</b>                                       | 65  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPCG12-90</b>                                       | 90  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPE6-5</b>                                          | 5   | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPF12-100 FR</b>                                    | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-100, XVF12-100A, EKF12-100A, LPFGS12-100L</b> | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-100A</b>                                      | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-100A FR</b>                                   | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-100B</b>                                      | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-100B FR</b>                                   | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-100C</b>                                      | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-100H FR</b>                                   | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-100H, CT12-100/19FT, KBF100-12</b>            | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-125 FR</b>                                    | 125 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-125, CT12-125FT</b>                           | 125 | 12 | - | - | - | - | - | HB  | - | - |

|                     |     |    |   |   |   |   |   |     |   |   |
|---------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>LPF12-150 FR</b> | 150 | 12 | - | - | - | - | - | V-0 | - | - |
|---------------------|-----|----|---|---|---|---|---|-----|---|---|

|                                                                                          |      |    |   |   |   |   |   |     |   |   |
|------------------------------------------------------------------------------------------|------|----|---|---|---|---|---|-----|---|---|
| <b>LPF12-150, 12LFT-150, EKF12-150B</b>                                                  | 150  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-150A FR</b>                                                                     | 150  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-150A, CT12-150FT</b>                                                            | 150  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-150B</b>                                                                        | 150  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-150B FR</b>                                                                     | 150  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-180 FR, LHTF12-150, LHTF12-200, LOP12-135FT FR, LOP12-135FT, LOP12-180FT FR</b> | 180  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-180, LPF12-170, LPF12-165, LOP12-180FT, CT12-180FT, CT12-180FT</b>              | 180  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-200 FR</b>                                                                      | 200  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-200, CT12-200FT</b>                                                             | 200  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-40B FR</b>                                                                      | 39.4 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-55 FR</b>                                                                       | 55   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-55, CT12-55FT</b>                                                               | 55   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-70</b>                                                                          | 75   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-70 FR</b>                                                                       | 75   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-75 FR</b>                                                                       | 75   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-75, CT12-75FT</b>                                                               | 75   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPF12-90</b>                                                                          | 90   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-90 FR</b>                                                                       | 90   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPF12-90H FR, FT12-90 FR</b>                                                          | 90   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPFG12-100, LPFGS12-100</b>                                                           | 90   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-100H</b>                                                                       | 90   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-100HS, LPFGS12-100H</b>                                                        | 90   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-100L</b>                                                                       | 90   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-130</b>                                                                        | 135  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-150</b>                                                                        | 135  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPFG12-150HS</b>                                                                      | 150  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPFG12-150L</b>                                                                       | 135  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-150S, LPFGS12-150</b>                                                          | 135  | 12 | - | - | - | - | - | HB  | - | - |

|                                                                             |     |    |   |   |   |   |   |     |   |   |
|-----------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>LPFG12-170HS</b>                                                         | 170 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPFG12-180, LPFG12-180S</b>                                              | 200 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-190S, LPFGS12-200</b>                                             | 200 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-50HS</b>                                                          | 50  | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-70</b>                                                            | 75  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-70S, LPFGS12-70, LPG12-75S, LPGS12-75</b>                         | 75  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFG12-85H</b>                                                           | 90  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPFGS12-180</b>                                                          | 200 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-10</b>                                                             | 10  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-100 FR</b>                                                         | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-100, DGM12100L, 883-8866</b>                                       | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-100S, LPGS12-100</b>                                               | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-110</b>                                                            | 110 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-110 FR</b>                                                         | 110 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-120S, LPGS12-120</b>                                               | 110 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-125</b>                                                            | 125 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-125 FR</b>                                                         | 125 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-140 FR</b>                                                         | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-140, DGM12150L, LPG12-150S, LPGS12-150, LPG12-140S, LPGS12-140</b> | 140 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-15</b>                                                             | 15  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-150</b>                                                            | 150 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-17 FR</b>                                                          | 17  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-18S, LPG12-17, 883-8844</b>                                        | 17  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-200 FR</b>                                                         | 200 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-200, LPG12-200S, LPGS12-200, DGM12200L</b>                         | 200 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-230, LPG12-250S, LPGS12-250</b>                                    | 230 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-24</b>                                                             | 24  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-24 FR</b>                                                          | 24  | 12 | - | - | - | - | - | V-0 | - | - |

|                                                        |    |    |   |   |   |   |   |     |   |   |
|--------------------------------------------------------|----|----|---|---|---|---|---|-----|---|---|
| <b>LPG12-24, LPCG12-24, LPCG12-24P</b>                 | 24 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-24H</b>                                       | 24 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-24S</b>                                       | 24 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-26 FR</b>                                     | 26 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-26, LPG12-28S, LPGS12-28, 883-8853</b>        | 26 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-26S</b>                                       | 26 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-31 FR, DGW12-30 FR, LPCG12-30</b>             | 31 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-31, DGW12-30, NDCG12-31NB</b>                 | 31 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-31S</b>                                       | 31 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-33S, LPGS12-33</b>                            | 31 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-38 FR</b>                                     | 38 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-38, LPCG12-40, DGM1240L, 883-8850</b>         | 38 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-38S, LPGS12-38</b>                            | 38 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-4</b>                                         | 4  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-40</b>                                        | 40 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-40 FR</b>                                     | 40 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-45, LPCG12-45, DGM1250L</b>                   | 45 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-5</b>                                         | 5  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-50 FR</b>                                     | 50 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-50, LPCG12-50, NDCG12-50I</b>                 | 50 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-50L FR</b>                                    | 50 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-50L, LP12-60(GROUP 34), LPC12-60, ED12600</b> | 50 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-50S</b>                                       | 50 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-55(I)</b>                                     | 55 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-55(II), LHT12-50</b>                          | 55 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-55(III)</b>                                   | 55 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-55S</b>                                       | 55 | 12 | - | - | - | - | - | HB  | - | - |

|                           |    |    |   |   |   |   |   |     |   |   |
|---------------------------|----|----|---|---|---|---|---|-----|---|---|
| <b>LPG12-60 FR</b>        | 60 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-60, DGM1260L</b> | 60 | 12 | - | - | - | - | - | HB  | - | - |

|                                                               |      |    |   |   |   |   |   |     |   |   |
|---------------------------------------------------------------|------|----|---|---|---|---|---|-----|---|---|
| <b>LPG12-60, DGM1260L, LPCG12-60A, 883-8869</b>               | 60   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-65</b>                                               | 65   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-65 FR</b>                                            | 65   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-65S, LPGS12-65</b>                                   | 65   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-7</b>                                                | 7    | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-70</b>                                               | 70   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-70H FR</b>                                           | 70   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-70H, DGM1280L, LPCG12-70, LPCG12-70A, NDCG12-70I</b> | 70   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-70S</b>                                              | 70   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-75</b>                                               | 75   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-75HS</b>                                             | 70   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-8</b>                                                | 8    | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-80, DGM1275</b>                                      | 80   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-80S, LPGS12-80</b>                                   | 80   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-85 FR</b>                                            | 85   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPG12-85, DGM1290L, 86003-004</b>                          | 85   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG12-90, DGM1290, LPG12-90S, LPGS12-90</b>                | 90   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPG2-100, LPGS2-100</b>                                    | 106  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-1000 FR</b>                                           | 1060 | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPG2-1000, LPGS2-1000, RMTS2-1000</b>                      | 1060 | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-1000H</b>                                             | 1060 | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-1200</b>                                              | 1272 | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-130</b>                                               | 138  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-150</b>                                               | 159  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-1500, LPGS2-1500</b>                                  | 1590 | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-1500H</b>                                             | 1590 | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-200 FR</b>                                            | 212  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPG2-200, LPGS2-200</b>                                    | 212  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-2000</b>                                              | 2120 | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-2000H</b>                                             | 2120 | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPG2-250</b>                                               | 265  | 2  | - | - | - | - | - | HB  | - | - |

|                     |      |   |   |   |   |   |   |     |   |   |
|---------------------|------|---|---|---|---|---|---|-----|---|---|
| LPG2-250            | 265  | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-2500           | 2650 | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-300 FR         | 318  | 2 | - | - | - | - | - | V-0 | - | - |
| LPG2-300, LPGS2-300 | 318  | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-3000           | 3180 | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-3000H          | 3180 | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-350            | 371  | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-3500           | 3170 | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-3500H          | 3170 | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-400 FR         | 424  | 2 | - | - | - | - | - | V-0 | - | - |
| LPG2-400, LPGS2-400 | 424  | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-500 FR         | 530  | 2 | - | - | - | - | - | V-0 | - | - |
| LPG2-500, LPGS2-500 | 530  | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-600 FR         | 636  | 2 | - | - | - | - | - | V-0 | - | - |
| LPG2-600, LPGS2-600 | 636  | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-65             | 69   | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-75             | 79.5 | 2 | - | - | - | - | - | HB  | - | - |
| LPG2-800 FR         | 848  | 2 | - | - | - | - | - | V-0 | - | - |
| LPG2-800, LPGS2-800 | 848  | 2 | - | - | - | - | - | HB  | - | - |
| LPG6-10             | 10   | 6 | - | - | - | - | - | HB  | - | - |
| LPG6-12             | 12   | 6 | - | - | - | - | - | HB  | - | - |
| LPG6-13             | 13   | 6 | - | - | - | - | - | HB  | - | - |
| LPG6-150            | 150  | 6 | - | - | - | - | - | HB  | - | - |
| LPG6-170            | -    | - | - | - | - | - | - | HB  | - | - |
| LPG6-20             | 20   | 6 | - | - | - | - | - | HB  | - | - |
| LPG6-200            | 200  | 6 | - | - | - | - | - | HB  | - | - |
| LPG6-30             | 30   | 6 | - | - | - | - | - | HB  | - | - |
| LPG6-4              | 4    | 6 | - | - | - | - | - | HB  | - | - |
| LPG6-450            | -    | - | - | - | - | - | - | HB  | - | - |
| LPG6-50             | 50   | 6 | - | - | - | - | - | HB  | - | - |
| LPG6-6              | 6    | 6 | - | - | - | - | - | HB  | - | - |
| LPG6-7              | 7    | 6 | - | - | - | - | - | HB  | - | - |

|        |   |   |   |   |   |   |   |    |   |   |
|--------|---|---|---|---|---|---|---|----|---|---|
| LPG6-8 | 8 | 6 | - | - | - | - | - | HB | - | - |
| LPG6-9 | 9 | 6 | - | - | - | - | - | HB | - | - |

|                                    |     |    |   |   |   |   |   |     |   |   |
|------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| LPG6-8.5                           | 8.5 | 6  | - | - | - | - | - | HB  | - | - |
| LPGS12-110                         | 110 | 12 | - | - | - | - | - | HB  | - | - |
| LPGS12-132                         | 132 | 12 | - | - | - | - | - | HB  | - | - |
| LPGS12-150 FR                      | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| LPGS12-154                         | 154 | 12 | - | - | - | - | - | HB  | - | - |
| LPGS12-190                         | 190 | 12 | - | - | - | - | - | HB  | - | - |
| LPGS12-200                         | 200 | 12 | - | - | - | - | - | HB  | - | - |
| LPGS12-200B                        | 200 | 12 | - | - | - | - | - | HB  | - | - |
| LPGS12-210                         | 210 | 12 | - | - | - | - | - | HB  | - | - |
| LPGS12-230                         | 230 | 12 | - | - | - | - | - | HB  | - | - |
| LPGS12-250                         | 250 | 12 | - | - | - | - | - | HB  | - | - |
| LPGS12-88                          | 88  | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-100 FR                       | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-100, CTH100-12               | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-12                           | 12  | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-12 FR                        | 12  | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-120 FR                       | 120 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-120, CTH120-12               | 120 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-140 FR                       | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-140, LHP12565W, LOP12-134 FR | 140 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-150 FR                       | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-150, XVL2-150, CTH150-12     | 150 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-200 FR                       | 200 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-200, ED122200, CTH200-12     | 200 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-24 FR                        | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-24, CTH24-12, CT24-12L       | 24  | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-24H                          | 24  | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-24H FR                       | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-250                          | 250 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-250 FR                       | 250 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-26                           | 26  | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-26 FR                        | 26  | 12 | - | - | - | - | - | V-0 | - | - |

|                                       |    |    |   |   |   |   |   |     |   |   |
|---------------------------------------|----|----|---|---|---|---|---|-----|---|---|
| LPL12-26 FR                           | 26 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-26D                             | 28 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-28                              | 28 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-28 FR                           | 28 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-28H                             | 28 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-28H FR                          | 28 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-38                              | 38 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-38 FR                           | 38 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-4.5                             | 5  | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-4.5 FR                          | 5  | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-40 FR                           | 40 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-40, CTH40-12, KB40-12D, KR40-12 | 40 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-45 FR                           | 45 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-45, USL12-42, ED12480, CTH45-12 | 45 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-50                              | 50 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-50 FR                           | 50 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-55 FR, DJM1255S FR              | 55 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-55, CTH55-12                    | 55 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-6.0                             | 7  | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-6.0 FR                          | 7  | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-60                              | 60 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-60 FR                           | 60 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-65                              | 65 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-65 FR                           | 65 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-65M                             | 70 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-65M FR                          | 70 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-7.0                             | 7  | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-7.0 FR                          | 7  | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-70 FR                           | 70 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-70, CTH70-12                    | 70 | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-75                              | 75 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-75 FR                           | 75 | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-75, LPL12-75L                   | 75 | 12 | - | - | - | - | - | HB  | - | - |

|                          |      |    |   |   |   |   |   |     |   |   |
|--------------------------|------|----|---|---|---|---|---|-----|---|---|
| LPL12-75, LPL12-75L      | 75   | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-90 FR              | 90   | 12 | - | - | - | - | - | V-0 | - | - |
| LPL12-90H                | 90   | 12 | - | - | - | - | - | HB  | - | - |
| LPL12-90H FR, LHR12355W  | 90   | 12 | - | - | - | - | - | V-0 | - | - |
| LPL2-100                 | 100  | 2  | - | - | - | - | - | HB  | - | - |
| LPL2-100 FR              | 100  | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-1000                | 1000 | 2  | - | - | - | - | - | HB  | - | - |
| LPL2-1000 FR, LPL2-1000M | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-1000M               | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-1200                | 1200 | 2  | - | - | - | - | - | HB  | - | - |
| LPL2-1200 FR             | 1200 | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-150                 | 150  | 2  | - | - | - | - | - | HB  | - | - |
| LPL2-150 FR              | 150  | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-1500                | 1500 | 2  | - | - | - | - | - | HB  | - | - |
| LPL2-1500 FR             | 1500 | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-1800                | 1800 | 2  | - | - | - | - | - | HB  | - | - |
| LPL2-1800 FR             | 1800 | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-200                 | 200  | 2  | - | - | - | - | - | HB  | - | - |
| LPL2-200 FR, LPL2-200M   | 200  | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-2000                | 2000 | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-2000 FR             | 2000 | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-200H, LPL2-200H V0  | 200  | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-200M, DJ200M        | 200  | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-250                 | 250  | 2  | - | - | - | - | - | HB  | - | - |
| LPL2-250 FR              | 250  | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-2500                | 2500 | 2  | - | - | - | - | - | HB  | - | - |
| LPL2-2500 FR             | 2500 | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-300                 | 300  | 2  | - | - | - | - | - | HB  | - | - |
| LPL2-300 FR, LPL2-300M   | 300  | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-3000                | 3000 | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-3000 FR             | 3000 | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-300M, DJ300M        | 300  | 2  | - | - | - | - | - | V-0 | - | - |
| LPL2-350                 | 350  | 2  | - | - | - | - | - | HB  | - | - |

|                         |      |   |   |   |   |   |   |     |   |   |
|-------------------------|------|---|---|---|---|---|---|-----|---|---|
| LPL2-350                | 350  | 2 | - | - | - | - | - | HB  | - | - |
| LPL2-350 FR             | 350  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-3500               | 3500 | 2 | - | - | - | - | - | HB  | - | - |
| LPL2-3500 FR            | 3500 | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-400                | 400  | 2 | - | - | - | - | - | HB  | - | - |
| LPL2-400 FR, LPL2-400M  | 400  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-400H, LPL2-400H V0 | 400  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-400M, DJ400M       | 400  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-450                | 450  | 2 | - | - | - | - | - | HB  | - | - |
| LPL2-450 FR             | 450  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-500                | 500  | 2 | - | - | - | - | - | HB  | - | - |
| LPL2-500 FR, LPL2-500M  | 500  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-500M, DJ500M       | 500  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-600                | 600  | 2 | - | - | - | - | - | HB  | - | - |
| LPL2-600 FR, LPL2-600M  | 600  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-600M, DJ600M       | 600  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-700                | 700  | 2 | - | - | - | - | - | HB  | - | - |
| LPL2-700 FR             | 700  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-800                | 800  | 2 | - | - | - | - | - | HB  | - | - |
| LPL2-800 FR LPL2-800M,  | 800  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-800M, DJ800M       | 800  | 2 | - | - | - | - | - | V-0 | - | - |
| LPL2-900                | 1000 | 2 | - | - | - | - | - | HB  | - | - |
| LPL2-900 FR             | 1000 | 2 | - | - | - | - | - | V-0 | - | - |
| LPL4-8.0                | 9    | 4 | - | - | - | - | - | HB  | - | - |
| LPL4-8.0 FR             | 9    | 4 | - | - | - | - | - | V-0 | - | - |
| LPL6-100                | 100  | 6 | - | - | - | - | - | HB  | - | - |
| LPL6-100 FR             | 100  | 6 | - | - | - | - | - | V-0 | - | - |
| LPL6-11                 | 12   | 6 | - | - | - | - | - | HB  | - | - |
| LPL6-11 FR              | 12   | 6 | - | - | - | - | - | V-0 | - | - |
| LPL6-120                | 120  | 6 | - | - | - | - | - | HB  | - | - |
| LPL6-120 FR             | 120  | 6 | - | - | - | - | - | V-0 | - | - |
| LPL6-150                | 150  | 6 | - | - | - | - | - | HB  | - | - |

|             |     |   |   |   |   |   |   |     |   |   |
|-------------|-----|---|---|---|---|---|---|-----|---|---|
| LPL6-150 FR | 150 | 6 | - | - | - | - | - | V-0 | - | - |
|-------------|-----|---|---|---|---|---|---|-----|---|---|

|                                        |     |    |   |   |   |   |   |     |   |   |
|----------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>LPL6-18</b>                         | 20  | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPL6-18 FR</b>                      | 20  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPL6-20</b>                         | 20  | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPL6-20 FR</b>                      | 20  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPL6-200</b>                        | 200 | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPL6-200 FR</b>                     | 200 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPL6-36</b>                         | 36  | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPL6-36 FR</b>                      | 36  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPL6-6.5</b>                        | 7   | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPL6-6.5 FR</b>                     | 7   | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPL6-60</b>                         | 60  | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPL6-60 FR</b>                      | 60  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPL6-9.0</b>                        | 10  | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPL6-9.0 FR</b>                     | 10  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-100FT</b>                     | 90  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-100FT FR</b>                  | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-105</b>                       | 104 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-115 FR</b>                    | 115 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-115, 12LS-120S, LPC12-110</b> | 115 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-115, BW121000</b>             | 110 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-115FT</b>                     | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-115FT FR</b>                  | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-125</b>                       | 127 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-135</b>                       | 138 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-145</b>                       | 144 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-145FT</b>                     | 125 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-145FT FR</b>                  | 125 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-160</b>                       | 140 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-160 FR</b>                    | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-170</b>                       | 173 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-170FT</b>                     | 150 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-170FT FR</b>                  | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-18, LPL12-18, CT18-12L</b>    | 18  | 12 | - | - | - | - | - | HB  | - | - |

|                            |      |    |   |   |   |   |   |     |   |   |
|----------------------------|------|----|---|---|---|---|---|-----|---|---|
| <b>LPS12-20</b>            | 20   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-20 FR</b>         | 20   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-210</b>           | 207  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-230</b>           | 230  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-285</b>           | 288  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-30</b>            | 28   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-30 FR</b>         | 28   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-36</b>            | 33   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-36 FR</b>         | 33   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-38</b>            | 38.1 | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-40</b>            | 38   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-40 FR</b>         | 38   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-45FT</b>          | 55   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-45FT FR</b>       | 55   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-50</b>            | 45   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-50 FR</b>         | 45   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-55 FR</b>         | 50   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-55, LP12-55RP</b> | 50   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-58</b>            | 58   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-60FT</b>          | 55   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-60FT FR</b>       | 55   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-7.5</b>           | 7    | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-7.5 FR</b>        | 7    | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-75</b>            | 65   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-75 FR</b>         | 65   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-85</b>            | 75   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-85 FR</b>         | 75   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-85FT</b>          | 75   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-85FT FR</b>       | 75   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS12-90</b>            | 80   | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPS12-90 FR</b>         | 80   | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPS2-1000</b>           | 800  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPS2-1000 FR</b>        | 800  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPS2-1100</b>           | 1000 | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPS2-1100 FR</b>        | 1000 | 2  | - | - | - | - | - | V-0 | - | - |

|               |      |   |   |   |   |   |   |     |   |   |
|---------------|------|---|---|---|---|---|---|-----|---|---|
| LPS2-1100     | 1000 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-1100 FR  | 1000 | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-1100H    | 1000 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-1100H FR | 1000 | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-115      | 100  | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-115 FR   | 100  | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-1350     | 1200 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-1350 FR  | 1200 | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-1350H    | 1200 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-1350H FR | 1200 | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-170      | 150  | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-170 FR   | 150  | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-1700     | 1500 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-1700 FR  | 1500 | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-1700H    | 1500 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-1700H FR | 1500 | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-2000     | 1800 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-2000 FR  | 1800 | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-230      | 200  | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-230 FR   | 200  | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-2300     | 2000 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-2300 FR  | 2000 | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-2300H    | 2000 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-2300H FR | 2000 | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-2800     | 2500 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-2800 FR  | 2500 | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-285      | 250  | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-285 FR   | 250  | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-350      | 300  | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-350 FR   | 300  | 2 | - | - | - | - | - | V-0 | - | - |
| LPS2-3500     | 3000 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-3500 FR  | 3000 | 2 | - | - | - | - | - | V-0 | - | - |

|               |      |   |   |   |   |   |   |     |   |   |
|---------------|------|---|---|---|---|---|---|-----|---|---|
| LPS2-3500H    | 3000 | 2 | - | - | - | - | - | HB  | - | - |
| LPS2-3500H FR | 3000 | 2 | - | - | - | - | - | V-0 | - | - |

|                                                                                                  |      |    |   |   |   |   |   |     |   |   |
|--------------------------------------------------------------------------------------------------|------|----|---|---|---|---|---|-----|---|---|
| <b>LPS2-3500H FR</b>                                                                             | 3000 | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPS2-400</b>                                                                                  | 350  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPS2-400 FR</b>                                                                               | 350  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPS2-4000</b>                                                                                 | 3500 | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPS2-4000 FR</b>                                                                              | 3500 | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPS2-450</b>                                                                                  | 400  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPS2-450 FR</b>                                                                               | 400  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPS2-500</b>                                                                                  | 450  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPS2-500 FR</b>                                                                               | 450  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPS2-550</b>                                                                                  | 500  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPS2-550 FR</b>                                                                               | 500  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPS2-700</b>                                                                                  | 600  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPS2-700 FR</b>                                                                               | 600  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPS2-800</b>                                                                                  | 700  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPS2-800 FR</b>                                                                               | 700  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPS2-900</b>                                                                                  | 800  | 2  | - | - | - | - | - | HB  | - | - |
| <b>LPS2-900 FR</b>                                                                               | 800  | 2  | - | - | - | - | - | V-0 | - | - |
| <b>LPS6-115</b>                                                                                  | 100  | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPS6-115 FR</b>                                                                               | 100  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPS6-170</b>                                                                                  | 150  | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPS6-170 FR</b>                                                                               | 150  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPS6-230</b>                                                                                  | 230  | 6  | - | - | - | - | - | HB  | - | - |
| <b>LPS6-230 FR</b>                                                                               | 230  | 6  | - | - | - | - | - | V-0 | - | - |
| <b>LPX12-1.2</b>                                                                                 | 1.2  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPX12-100 FR, LHR12430W, LHR12400W, LHR12450W, LHP12420W, LHP12470W, LHR12440W</b>            | 100  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>LPX12-100, U12V430P/B, LCP12-400, LCP12-450, XVP12-400, XVP12-450, U12V400P/B, U12V425P/B</b> | 100  | 12 | - | - | - | - | - | HB  | - | - |
| <b>LPX12-12 FR, CT12-12H FR</b>                                                                  | 14   | 12 | - | - | - | - | - | V-0 | - | - |

|                                     |    |    |   |   |   |   |   |    |   |   |
|-------------------------------------|----|----|---|---|---|---|---|----|---|---|
| <b>LPX12-12, CT12-12H, CT12-50W</b> | 14 | 12 | - | - | - | - | - | HB | - | - |
|-------------------------------------|----|----|---|---|---|---|---|----|---|---|

|                                                                                                                 |     |    |   |   |   |   |   |     |   |   |
|-----------------------------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| LPX12-120 FR,<br>LHR12460W, DJM12120H                                                                           | 120 | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-120, XPE12-390,<br>CT12-480W                                                                              | 120 | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-150 FR,<br>LHR12550W                                                                                      | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-150, U12V490P/B,<br>CT12-485W                                                                             | 150 | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-17                                                                                                        | 20  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-18                                                                                                        | 20  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-18 FR                                                                                                     | 20  | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-2.2                                                                                                       | 2.3 | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-2.2 FR                                                                                                    | 2.3 | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-20 FR                                                                                                     | 22  | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-20, CT12-80W                                                                                              | 22  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-200 FR,<br>LHR12660W                                                                                      | 200 | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-200, U12V740P/B,<br>U12V655P/B,<br>U12V590P/B, XPE12-650,<br>LCP12-740,XVP12-740,<br>CT12-675W            | 200 | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-24 FR                                                                                                     | 26  | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-24, CT12-100W                                                                                             | 26  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-250 FR                                                                                                    | 250 | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-250, U12V800P/B,<br>LCP12-810, XVP12-810,<br>CT12-780W                                                    | 250 | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-3.2                                                                                                       | 3.2 | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-3.2 FR                                                                                                    | 3.2 | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-35, BW12350,<br>ES12350, LPC12-35S,<br>LP12-35, LP12-35H, LP12-<br>35E, MU-1 SLD M-X, MU-<br>1 SLD M FT-X | 35  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-38 FR, LCP12-125,<br>XVP12-125, CT12-125W                                                                 | 38  | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-38, U12V125P/B,<br>XPE12-125, LCP12-135,<br>XVP12-135                                                     | 38  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-5.4 FR                                                                                                    | 5.4 | 12 | - | - | - | - | - | V-0 | - | - |

|                                                      |      |    |   |   |   |   |   |     |   |   |
|------------------------------------------------------|------|----|---|---|---|---|---|-----|---|---|
| LPX12-5.4, CT12-20W                                  | 5.4  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-6.0 FR, LHR1225W, LHR1226W, LHP1226W, 198-4036 | 7    | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-6.0, LCP12-24, XVP12-24, LHR1226W, CTH7-12     | 7    | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-6.5 FR, LHR1224W                               | 6.5  | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-6.5, LHR1224W, LP12-28W                        | 6.5  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-65 FR                                          | 65   | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-65, XPE12-225, LCP12-225, XVP12-225            | 65   | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-7.0 FR                                         | 7.2  | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-7.0, LCP12-26, XVP12-26, XVP12-28, LCP12-28    | 7.2  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-7.6 FR                                         | 7.6  | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-7.6, LCP12-38, XVP12-38                        | 7.6  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-72                                             | 72   | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-72 FR                                          | 72   | 12 | - | - | - | - | - | V-0 | - | - |
| LPX12-9.0                                            | 8.6  | 12 | - | - | - | - | - | HB  | - | - |
| LPX12-9.0 FR                                         | 8.6  | 12 | - | - | - | - | - | V-0 | - | - |
| LPX2-100                                             | 100  | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-100 FR                                          | 100  | 2  | - | - | - | - | - | V-0 | - | - |
| LPX2-1000                                            | 1000 | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-1000 FR                                         | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| LPX2-1000H                                           | 1000 | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-1000H FR                                        | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| LPX2-1200                                            | 1200 | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-1200 FR                                         | 1200 | 2  | - | - | - | - | - | V-0 | - | - |
| LPX2-1200H                                           | 1200 | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-1200H FR                                        | 1200 | 2  | - | - | - | - | - | V-0 | - | - |
| LPX2-130                                             | 130  | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-130 FR                                          | 130  | 2  | - | - | - | - | - | V-0 | - | - |

|             |     |   |   |   |   |   |   |     |   |   |
|-------------|-----|---|---|---|---|---|---|-----|---|---|
| LPX2-150    | 150 | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-150 FR | 150 | 2 | - | - | - | - | - | V-0 | - | - |

|               |      |   |   |   |   |   |   |     |   |   |
|---------------|------|---|---|---|---|---|---|-----|---|---|
| LPX2-150 FR   | 150  | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-1500     | 1500 | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-1500 FR  | 1500 | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-1500H    | 1500 | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-1500H FR | 1500 | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-1800     | 1800 | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-1800 FR  | 1800 | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-200      | 200  | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-200 FR   | 200  | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-2000     | 2000 | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-2000 FR  | 2000 | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-2000H    | 2000 | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-2000H FR | 2000 | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-250      | 250  | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-250 FR   | 250  | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-2500     | 2500 | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-2500 FR  | 2500 | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-300      | 300  | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-300 FR   | 300  | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-3000     | 3000 | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-3000 FR  | 3000 | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-3000H    | 3000 | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-3000H FR | 3000 | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-350      | 350  | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-350 FR   | 350  | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-3500     | 3500 | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-3500 FR  | 3500 | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-400      | 400  | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-400 FR   | 400  | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-450      | 450  | 2 | - | - | - | - | - | HB  | - | - |
| LPX2-450 FR   | 450  | 2 | - | - | - | - | - | V-0 | - | - |
| LPX2-500      | 450  | 2 | - | - | - | - | - | HB  | - | - |

|             |     |   |   |   |   |   |   |     |   |   |
|-------------|-----|---|---|---|---|---|---|-----|---|---|
| LPX2-500 FR | 450 | 2 | - | - | - | - | - | V-0 | - | - |
|-------------|-----|---|---|---|---|---|---|-----|---|---|

|                     |      |    |   |   |   |   |   |     |   |   |
|---------------------|------|----|---|---|---|---|---|-----|---|---|
| LPX2-600            | 600  | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-600 FR, DJ650H | 600  | 2  | - | - | - | - | - | V-0 | - | - |
| LPX2-65             | 65   | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-65 FR          | 65   | 2  | - | - | - | - | - | V-0 | - | - |
| LPX2-700            | 700  | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-700 FR         | 700  | 2  | - | - | - | - | - | V-0 | - | - |
| LPX2-72             | 75   | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-72 FR          | 75   | 2  | - | - | - | - | - | V-0 | - | - |
| LPX2-800            | 800  | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-800 FR         | 800  | 2  | - | - | - | - | - | V-0 | - | - |
| LPX2-900            | 900  | 2  | - | - | - | - | - | HB  | - | - |
| LPX2-900 FR         | 900  | 2  | - | - | - | - | - | V-0 | - | - |
| LPX6-100            | 100  | 6  | - | - | - | - | - | HB  | - | - |
| LPX6-100 FR         | 100  | 6  | - | - | - | - | - | V-0 | - | - |
| LPX6-120            | 120  | 6  | - | - | - | - | - | HB  | - | - |
| LPX6-120 FR         | 120  | 6  | - | - | - | - | - | V-0 | - | - |
| LPX6-150            | 150  | 6  | - | - | - | - | - | HB  | - | - |
| LPX6-150 FR         | 150  | 6  | - | - | - | - | - | V-0 | - | - |
| LPX6-200            | 200  | 6  | - | - | - | - | - | HB  | - | - |
| LPX6-200 FR         | 200  | 6  | - | - | - | - | - | V-0 | - | - |
| LRC2-1000           | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| LRC2-300            | 300  | 2  | - | - | - | - | - | V-0 | - | - |
| LRC2-400            | 400  | 2  | - | - | - | - | - | V-0 | - | - |
| LRC2-500            | 500  | 2  | - | - | - | - | - | V-0 | - | - |
| LRC2-600            | 600  | 2  | - | - | - | - | - | V-0 | - | - |
| LRC2-800            | 800  | 2  | - | - | - | - | - | V-0 | - | - |
| LRCF12-140          | 140  | 12 | - | - | - | - | - | V-0 | - | - |
| LRCF12-170          | 170  | 12 | - | - | - | - | - | V-0 | - | - |
| MB14-4              | 12   | 12 | - | - | - | - | - | HB  | - | - |
| MP1-6               | 1    | 6  | - | - | - | - | - | HB  | - | - |
| MP2.8-6P            | 2.8  | 6  | - | - | - | - | - | HB  | - | - |
| MP2.9-12R           | 2.9  | 12 | - | - | - | - | - | HB  | - | - |

|        |    |   |   |   |   |   |   |    |   |   |
|--------|----|---|---|---|---|---|---|----|---|---|
| MP20-6 | 20 | 6 | - | - | - | - | - | HB | - | - |
|--------|----|---|---|---|---|---|---|----|---|---|

|                                     |     |    |   |   |   |   |   |     |   |   |
|-------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>MP3-8</b>                        | 3.2 | 8  | - | - | - | - | - | HB  | - | - |
| <b>MP3.4-12</b>                     | 3.2 | 12 | - | - | - | - | - | HB  | - | - |
| <b>MP4-12D</b>                      | 4   | 12 | - | - | - | - | - | HB  | - | - |
| <b>MP4.5-4</b>                      | 4.5 | 4  | - | - | - | - | - | HB  | - | - |
| <b>MS2-300ULTRA</b>                 | 300 | 2  | - | - | - | - | - | HB  | - | - |
| <b>MS2-300ULTRA FR</b>              | 300 | 2  | - | - | - | - | - | V-0 | - | - |
| <b>MS2-500ULTRA</b>                 | 500 | 2  | - | - | - | - | - | HB  | - | - |
| <b>MS2-500ULTRA FR</b>              | 500 | 2  | - | - | - | - | - | V-0 | - | - |
| <b>PLC+C 160FT, 200 PLC</b>         | 160 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLC+C 180FT</b>                  | 170 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLC100</b>                       | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLC100FT</b>                     | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLC150FT</b>                     | 135 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLC190FT</b>                     | 170 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH+C 100</b>                    | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH+C 100FT</b>                  | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH+C 110FT</b>                  | 110 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH+C 150FT</b>                  | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH+C 170FT</b>                  | 170 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH+C 190FT</b>                  | 190 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH+C 210FT</b>                  | 210 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH+C 40FT</b>                   | 38  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH+C 62FT</b>                   | 62  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH+C 90FT</b>                   | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH100, LCP12-490, XVP12-490</b> | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH100FT</b>                     | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH100FT(A)</b>                  | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH110FT</b>                     | 110 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH110FT(A)</b>                  | 110 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH150FT</b>                     | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH150FT(A)</b>                  | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH170FT</b>                     | 170 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH170FT(A)</b>                  | 170 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH190FT</b>                     | 190 | 12 | - | - | - | - | - | V-0 | - | - |

|                                                                                           |     |    |   |   |   |   |   |     |   |   |
|-------------------------------------------------------------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>PLH190FT</b>                                                                           | 190 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH190FT(A)</b>                                                                        | 190 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH210FT</b>                                                                           | 210 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH210FT(A)</b>                                                                        | 210 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH40FT</b>                                                                            | 40  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH40FT(A)</b>                                                                         | 38  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH6-100</b>                                                                           | 100 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>PLH62FT</b>                                                                            | 62  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH62FT(A)</b>                                                                         | 62  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH90FT</b>                                                                            | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLH90FT(A)</b>                                                                         | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-165FT</b>                                                                        | 38  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-260FT</b>                                                                        | 62  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-260FT(A)</b>                                                                     | 62  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-330</b>                                                                          | 80  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-360</b>                                                                          | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-400</b>                                                                          | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-400FT</b>                                                                        | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-400FT(A)</b>                                                                     | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-420</b>                                                                          | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-450FT</b>                                                                        | 110 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-450FT(A)</b>                                                                     | 110 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-500</b>                                                                          | 125 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-540</b>                                                                          | 135 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-600FT</b>                                                                        | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-600FT(A), PLX12-620FT(A)</b>                                                     | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-620</b>                                                                          | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-700FT(A)</b>                                                                     | 190 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-700FT, LPF12-190, LHT12-190, LHTF12-190, FT12-190, LPFG12-190HS, LPFGS12-190</b> | 190 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>PLX12-730FT</b>                                                                        | 200 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>U12V350P/B</b>                                                                         | 85  | 12 | - | - | - | - | - | HB  | - | - |

|                          |     |    |   |   |   |   |   |     |   |   |
|--------------------------|-----|----|---|---|---|---|---|-----|---|---|
| U12V350P/B FR, DJM1285H  | 85  | 12 | - | - | - | - | - | -   | - | - |
| U12V765P/B               | 225 | 12 | - | - | - | - | - | HB  | - | - |
| U12V765P/B FR, DJM12225H | 225 | 12 | - | - | - | - | - | -   | - | - |
| US12-0.8                 | 0.8 | 12 | - | - | - | - | - | HB  | - | - |
| US12-0.8 FR              | 0.8 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-1.2                 | 1.2 | 12 | - | - | - | - | - | HB  | - | - |
| US12-1.2 FR              | 1.2 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-1.5                 | 1.5 | 12 | - | - | - | - | - | HB  | - | - |
| US12-1.5 FR              | 1.5 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-1.9                 | 1.9 | 12 | - | - | - | - | - | HB  | - | - |
| US12-1.9 FR              | 1.9 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-10                  | 10  | 12 | - | - | - | - | - | HB  | - | - |
| US12-10 FR               | 10  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-100                 | 100 | 12 | - | - | - | - | - | HB  | - | - |
| US12-100 FR              | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-10H                 | 10  | 12 | - | - | - | - | - | HB  | - | - |
| US12-10H FR              | 10  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-12                  | 12  | 12 | - | - | - | - | - | HB  | - | - |
| US12-12 FR               | 12  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-120 FR              | 120 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-120, 6-EV-120A      | 120 | 12 | - | - | - | - | - | HB  | - | - |
| US12-14                  | 14  | 12 | - | - | - | - | - | HB  | - | - |
| US12-14 FR               | 14  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-140                 | 140 | 12 | - | - | - | - | - | HB  | - | - |
| US12-140 FR              | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-15                  | 15  | 12 | - | - | - | - | - | HB  | - | - |
| US12-15 FR               | 15  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-150                 | 150 | 12 | - | - | - | - | - | HB  | - | - |
| US12-150 FR              | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-18                  | 18  | 12 | - | - | - | - | - | HB  | - | - |
| US12-18 FR               | 18  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-2.0C1               | 2   | 12 | - | - | - | - | - | HB  | - | - |
| US12-2.0C1 FR            | 2   | 12 | - | - | - | - | - | V-0 | - | - |

|               |     |    |   |   |   |   |   |     |   |   |
|---------------|-----|----|---|---|---|---|---|-----|---|---|
| US12-2.0CT FR | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| US12-2.0NP    | 2   | 12 | - | - | - | - | - | HB  | - | - |
| US12-2.0NP FR | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| US12-2.1      | 2.1 | 12 | - | - | - | - | - | HB  | - | - |
| US12-2.3      | 2.3 | 12 | - | - | - | - | - | HB  | - | - |
| US12-2.3 FR   | 2.3 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-2.3C     | 2.3 | 12 | - | - | - | - | - | HB  | - | - |
| US12-2.3C FR  | 2.3 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-2.5      | 2.5 | 12 | - | - | - | - | - | HB  | - | - |
| US12-2.5 FR   | 2.5 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-2.6      | 2.6 | 12 | - | - | - | - | - | HB  | - | - |
| US12-2.6 FR   | 2.6 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-2.8      | 2.8 | 12 | - | - | - | - | - | HB  | - | - |
| US12-2.8 FR   | 2.8 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-2.9      | 2.9 | 12 | - | - | - | - | - | HB  | - | - |
| US12-2.9 FR   | 2.9 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-20       | 20  | 12 | - | - | - | - | - | HB  | - | - |
| US12-20 FR    | 20  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-200      | 200 | 12 | - | - | - | - | - | HB  | - | - |
| US12-200 FR   | 200 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-230      | 230 | 12 | - | - | - | - | - | HB  | - | - |
| US12-24       | 24  | 12 | - | - | - | - | - | HB  | - | - |
| US12-24 FR    | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-24H      | 24  | 12 | - | - | - | - | - | HB  | - | - |
| US12-24H FR   | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-26       | 26  | 12 | - | - | - | - | - | HB  | - | - |
| US12-26 FR    | 26  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-28       | 28  | 12 | - | - | - | - | - | HB  | - | - |
| US12-28 FR    | 28  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-28H      | 28  | 12 | - | - | - | - | - | HB  | - | - |
| US12-28H FR   | 28  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-3.0      | 3   | 12 | - | - | - | - | - | HB  | - | - |
| US12-3.0 FR   | 3   | 12 | - | - | - | - | - | V-0 | - | - |
| US12-3.0      | 3   | 12 | - | - | - | - | - | HB  | - | - |

|                   |     |    |   |   |   |   |   |     |   |   |
|-------------------|-----|----|---|---|---|---|---|-----|---|---|
| US12-3.2          | 3.2 | 12 | - | - | - | - | - | HB  | - | - |
| US12-3.2 FR       | 3.2 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-3.5          | 3.5 | 12 | - | - | - | - | - | HB  | - | - |
| US12-3.5 FR       | 3.5 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-32           | 33  | 12 | - | - | - | - | - | HB  | - | - |
| US12-32 FR        | 33  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-33, USL12-33 | 33  | 12 | - | - | - | - | - | HB  | - | - |
| US12-35           | 33  | 12 | - | - | - | - | - | HB  | - | - |
| US12-35 FR        | 33  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-38           | 38  | 12 | - | - | - | - | - | HB  | - | - |
| US12-38 FR        | 38  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-4.0          | 2   | 12 | - | - | - | - | - | HB  | - | - |
| US12-4.0 FR       | 2   | 12 | - | - | - | - | - | V-0 | - | - |
| US12-4.0L         | 4   | 12 | - | - | - | - | - | HB  | - | - |
| US12-4.0L FR      | 4   | 12 | - | - | - | - | - | V-0 | - | - |
| US12-4.5          | 4.5 | 12 | - | - | - | - | - | HB  | - | - |
| US12-4.5 FR       | 4.5 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-40           | 40  | 12 | - | - | - | - | - | HB  | - | - |
| US12-40 FR        | 40  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-45 FR        | 45  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-45, 6-EV-45B | 45  | 12 | - | - | - | - | - | HB  | - | - |
| US12-5.0          | 5   | 12 | - | - | - | - | - | HB  | - | - |
| US12-5.0 FR       | 5   | 12 | - | - | - | - | - | V-0 | - | - |
| US12-5.0H         | 5   | 12 | - | - | - | - | - | HB  | - | - |
| US12-5.0H FR      | 5   | 12 | - | - | - | - | - | V-0 | - | - |
| US12-5.4          | 5.4 | 12 | - | - | - | - | - | HB  | - | - |
| US12-50 FR        | 50  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-50, 6-EV-50  | 50  | 12 | - | - | - | - | - | HB  | - | - |
| US12-55           | 55  | 12 | - | - | - | - | - | HB  | - | - |
| US12-55 FR        | 55  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-6.0          | 5.4 | 12 | - | - | - | - | - | HB  | - | - |
| US12-6.0 FR       | 5.4 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-6.0H         | 5.5 | 12 | - | - | - | - | - | HB  | - | - |
| US12-6.0H FR      | 5.5 | 12 | - | - | - | - | - | V-0 | - | - |

|                         |     |    |   |   |   |   |   |     |   |   |
|-------------------------|-----|----|---|---|---|---|---|-----|---|---|
| US12-6.0H FR            | 5.5 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-6.0L               | 6   | 12 | - | - | - | - | - | HB  | - | - |
| US12-6.0L FR            | 6   | 12 | - | - | - | - | - | V-0 | - | - |
| US12-60 FR              | 60  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-60, 6-EV-60B       | 60  | 12 | - | - | - | - | - | HB  | - | - |
| US12-65 FR              | 65  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-65, 6-EV-65B       | 65  | 12 | - | - | - | - | - | HB  | - | - |
| US12-7.0                | 7.0 | 12 | - | - | - | - | - | HB  | - | - |
| US12-7.0 FR             | 7.0 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-7.2                | 7.2 | 12 | - | - | - | - | - | HB  | - | - |
| US12-7.2 FR             | 7.2 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-7.5                | 7.5 | 12 | - | - | - | - | - | HB  | - | - |
| US12-7.5 FR             | 7.5 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-7.8                | 7.8 | 12 | - | - | - | - | - | HB  | - | - |
| US12-7.8 FR             | 7.8 | 12 | - | - | - | - | - | V-0 | - | - |
| US12-70                 | 70  | 12 | - | - | - | - | - | HB  | - | - |
| US12-70 FR              | 70  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-75                 | 75  | 12 | - | - | - | - | - | HB  | - | - |
| US12-75 FR, DJM1275H FR | 75  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-8.5                | 8   | 12 | - | - | - | - | - | HB  | - | - |
| US12-8.5 FR             | 8   | 12 | - | - | - | - | - | V-0 | - | - |
| US12-80                 | 80  | 12 | - | - | - | - | - | HB  | - | - |
| US12-80 FR              | 80  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-90 FR              | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| US12-90, 6-EV-90B       | 90  | 12 | - | - | - | - | - | HB  | - | - |
| US2-4.0                 | 4   | 2  | - | - | - | - | - | HB  | - | - |
| US2-4.0 FR              | 4   | 2  | - | - | - | - | - | V-0 | - | - |
| US24-1.3                | 1.3 | 24 | - | - | - | - | - | HB  | - | - |
| US24-1.3 FR             | 1.3 | 24 | - | - | - | - | - | V-0 | - | - |
| US24-3.5                | 3.5 | 24 | - | - | - | - | - | HB  | - | - |
| US24-3.5 FR             | 3.5 | 24 | - | - | - | - | - | V-0 | - | - |
| US24-4.0                | 4   | 24 | - | - | - | - | - | HB  | - | - |
| US24-4.0 FR             | 4   | 24 | - | - | - | - | - | V-0 | - | - |
| US24-4.5                | 4.5 | 24 | - | - | - | - | - | HB  | - | - |
| US24-4.5 FR             | 4.5 | 24 | - | - | - | - | - | V-0 | - | - |

|             |     |    |   |   |   |   |   |     |   |   |
|-------------|-----|----|---|---|---|---|---|-----|---|---|
| US24-4.5    | 4.5 | 24 | - | - | - | - | - | HB  | - | - |
| US24-4.5 FR | 4.5 | 24 | - | - | - | - | - | V-0 | - | - |
| US4-10      | 10  | 4  | - | - | - | - | - | HB  | - | - |
| US4-10 FR   | 10  | 4  | - | - | - | - | - | V-0 | - | - |
| US4-20      | 20  | 4  | - | - | - | - | - | HB  | - | - |
| US4-20 FR   | 20  | 4  | - | - | - | - | - | V-0 | - | - |
| US4-3.5     | 3.5 | 4  | - | - | - | - | - | HB  | - | - |
| US4-3.5 FR  | 3.5 | 4  | - | - | - | - | - | V-0 | - | - |
| US4-4.0     | 4   | 4  | - | - | - | - | - | HB  | - | - |
| US4-4.0 FR  | 4   | 4  | - | - | - | - | - | V-0 | - | - |
| US4-4.5     | 4.5 | 4  | - | - | - | - | - | HB  | - | - |
| US4-4.5 FR  | 4.5 | 4  | - | - | - | - | - | V-0 | - | - |
| US4-5.0     | 5   | 4  | - | - | - | - | - | HB  | - | - |
| US4-5.0 FR  | 5   | 4  | - | - | - | - | - | V-0 | - | - |
| US4-8.0     | 8   | 4  | - | - | - | - | - | HB  | - | - |
| US4-8.0 FR  | 8   | 4  | - | - | - | - | - | V-0 | - | - |
| US4-9.0     | 9   | 4  | - | - | - | - | - | HB  | - | - |
| US4-9.0 FR  | 9   | 4  | - | - | - | - | - | V-0 | - | - |
| US6-0.5     | 0.5 | 6  | - | - | - | - | - | HB  | - | - |
| US6-0.5 FR  | 0.5 | 6  | - | - | - | - | - | V-0 | - | - |
| US6-1.0     | 1   | 6  | - | - | - | - | - | HB  | - | - |
| US6-1.0 FR  | 1   | 6  | - | - | - | - | - | V-0 | - | - |
| US6-1.2     | 1.2 | 6  | - | - | - | - | - | HB  | - | - |
| US6-1.2 FR  | 1.2 | 6  | - | - | - | - | - | V-0 | - | - |
| US6-1.4     | 1.4 | 6  | - | - | - | - | - | HB  | - | - |
| US6-1.4 FR  | 1.4 | 6  | - | - | - | - | - | V-0 | - | - |
| US6-10      | 10  | 6  | - | - | - | - | - | HB  | - | - |
| US6-10 FR   | 10  | 6  | - | - | - | - | - | V-0 | - | - |
| US6-100     | 100 | 6  | - | - | - | - | - | HB  | - | - |
| US6-100 FR  | 100 | 6  | - | - | - | - | - | V-0 | - | - |
| US6-12      | 12  | 6  | - | - | - | - | - | HB  | - | - |
| US6-12 FR   | 12  | 6  | - | - | - | - | - | V-0 | - | - |
| US6-120     | 120 | 6  | - | - | - | - | - | HB  | - | - |
| US6-120 FR  | 120 | 6  | - | - | - | - | - | V-0 | - | - |

|            |     |   |   |   |   |   |   |     |   |   |
|------------|-----|---|---|---|---|---|---|-----|---|---|
| US6-120 FR | 120 | 6 | - | - | - | - | - | V-0 | - | - |
| US6-13     | 13  | 6 | - | - | - | - | - | HB  | - | - |
| US6-13 FR  | 13  | 6 | - | - | - | - | - | V-0 | - | - |
| US6-14     | 14  | 6 | - | - | - | - | - | HB  | - | - |
| US6-14 FR  | 14  | 6 | - | - | - | - | - | V-0 | - | - |
| US6-150    | 150 | 6 | - | - | - | - | - | HB  | - | - |
| US6-150 FR | 150 | 6 | - | - | - | - | - | V-0 | - | - |
| US6-2.0    | 2   | 6 | - | - | - | - | - | HB  | - | - |
| US6-2.0 FR | 2   | 6 | - | - | - | - | - | V-0 | - | - |
| US6-2.8    | 2.8 | 6 | - | - | - | - | - | HB  | - | - |
| US6-2.8 FR | 2.8 | 6 | - | - | - | - | - | V-0 | - | - |
| US6-20     | 20  | 6 | - | - | - | - | - | HB  | - | - |
| US6-20 FR  | 20  | 6 | - | - | - | - | - | V-0 | - | - |
| US6-200    | 200 | 6 | - | - | - | - | - | HB  | - | - |
| US6-200 FR | 200 | 6 | - | - | - | - | - | V-0 | - | - |
| US6-3.2    | 3.2 | 6 | - | - | - | - | - | HB  | - | - |
| US6-3.2 FR | 3.2 | 6 | - | - | - | - | - | V-0 | - | - |
| US6-36     | 36  | 6 | - | - | - | - | - | HB  | - | - |
| US6-36 FR  | 36  | 6 | - | - | - | - | - | V-0 | - | - |
| US6-4.0    | 4   | 6 | - | - | - | - | - | HB  | - | - |
| US6-4.0 FR | 4   | 6 | - | - | - | - | - | V-0 | - | - |
| US6-4.5    | 4.5 | 6 | - | - | - | - | - | HB  | - | - |
| US6-4.5 FR | 4.5 | 6 | - | - | - | - | - | V-0 | - | - |
| US6-42     | 42  | 6 | - | - | - | - | - | HB  | - | - |
| US6-42 FR  | 42  | 6 | - | - | - | - | - | V-0 | - | - |
| US6-5.0    | 5   | 6 | - | - | - | - | - | HB  | - | - |
| US6-5.0 FR | 5   | 6 | - | - | - | - | - | V-0 | - | - |
| US6-6.0    | 6   | 6 | - | - | - | - | - | HB  | - | - |
| US6-6.0 FR | 6   | 6 | - | - | - | - | - | V-0 | - | - |
| US6-6.5    | 6.5 | 6 | - | - | - | - | - | HB  | - | - |
| US6-6.5 FR | 6.5 | 6 | - | - | - | - | - | V-0 | - | - |
| US6-60     | 60  | 6 | - | - | - | - | - | HB  | - | - |

|           |    |   |   |   |   |   |   |     |   |   |
|-----------|----|---|---|---|---|---|---|-----|---|---|
| US6-60 FR | 60 | 6 | - | - | - | - | - | V-0 | - | - |
|-----------|----|---|---|---|---|---|---|-----|---|---|

|              |     |    |   |   |   |   |   |     |   |   |
|--------------|-----|----|---|---|---|---|---|-----|---|---|
| US6-7.0      | 7   | 6  | - | - | - | - | - | HB  | - | - |
| US6-7.0 FR   | 7   | 6  | - | - | - | - | - | V-0 | - | - |
| US6-7.2      | 7.2 | 6  | - | - | - | - | - | HB  | - | - |
| US6-7.2 FR   | 7.2 | 6  | - | - | - | - | - | V-0 | - | - |
| US6-7.5      | 7.5 | 6  | - | - | - | - | - | HB  | - | - |
| US6-7.5 FR   | 7.5 | 6  | - | - | - | - | - | V-0 | - | - |
| US6-7.8      | 7.8 | 6  | - | - | - | - | - | HB  | - | - |
| US6-7.8 FR   | 7.8 | 6  | - | - | - | - | - | V-0 | - | - |
| US6-8.5      | 8.5 | 6  | - | - | - | - | - | HB  | - | - |
| US6-8.5 FR   | 8.5 | 6  | - | - | - | - | - | V-0 | - | - |
| US6-8.5L     | 8   | 6  | - | - | - | - | - | HB  | - | - |
| US6-8.5L FR  | 8   | 6  | - | - | - | - | - | V-0 | - | - |
| US8-3.2      | 3.2 | 8  | - | - | - | - | - | HB  | - | - |
| US8-3.2 FR   | 3.2 | 8  | - | - | - | - | - | V-0 | - | - |
| USC12-100    | 100 | 12 | - | - | - | - | - | HB  | - | - |
| USC12-100 FR | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-120    | 120 | 12 | - | - | - | - | - | HB  | - | - |
| USC12-120 FR | 120 | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-13     | 14  | 12 | - | - | - | - | - | HB  | - | - |
| USC12-13 FR  | 14  | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-150    | 150 | 12 | - | - | - | - | - | HB  | - | - |
| USC12-150 FR | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-18     | 20  | 12 | - | - | - | - | - | HB  | - | - |
| USC12-18 FR  | 20  | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-200    | 200 | 12 | - | - | - | - | - | HB  | - | - |
| USC12-200 FR | 200 | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-24     | 26  | 12 | - | - | - | - | - | HB  | - | - |
| USC12-24 FR  | 26  | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-24H    | 28  | 12 | - | - | - | - | - | HB  | - | - |
| USC12-24H FR | 28  | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-33     | 33  | 12 | - | - | - | - | - | HB  | - | - |
| USC12-33 FR  | 33  | 12 | - | - | - | - | - | V-0 | - | - |

|             |    |    |   |   |   |   |   |     |   |   |
|-------------|----|----|---|---|---|---|---|-----|---|---|
| USC12-38 FR | 38 | 12 | - | - | - | - | - | V-0 | - | - |
|-------------|----|----|---|---|---|---|---|-----|---|---|

|                     |     |    |   |   |   |   |   |     |   |   |
|---------------------|-----|----|---|---|---|---|---|-----|---|---|
| USC12-38, 6-EVF-38B | 38  | 12 | - | - | - | - | - | HB  | - | - |
| USC12-5.6           | 5.4 | 12 | - | - | - | - | - | HB  | - | - |
| USC12-5.6 FR        | 5.4 | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-55            | 55  | 12 | - | - | - | - | - | HB  | - | - |
| USC12-55 FR         | 55  | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-7.2           | 7.2 | 12 | - | - | - | - | - | HB  | - | - |
| USC12-7.2 FR        | 7.2 | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-75            | 75  | 12 | - | - | - | - | - | HB  | - | - |
| USC12-75 FR         | 75  | 12 | - | - | - | - | - | V-0 | - | - |
| USC12-8.0           | 8   | 12 | - | - | - | - | - | HB  | - | - |
| USC12-8.0 FR        | 8   | 12 | - | - | - | - | - | V-0 | - | - |
| USC6-13             | 14  | 6  | - | - | - | - | - | HB  | - | - |
| USC6-13 FR          | 14  | 6  | - | - | - | - | - | V-0 | - | - |
| USC6-5.6            | 6   | 6  | - | - | - | - | - | HB  | - | - |
| USC6-5.6 FR         | 6   | 6  | - | - | - | - | - | V-0 | - | - |
| USF12-100           | 100 | 12 | - | - | - | - | - | HB  | - | - |
| USF12-100 FR        | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| USF12-100H          | 100 | 12 | - | - | - | - | - | HB  | - | - |
| USF12-100H FR       | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| USF12-125           | 125 | 12 | - | - | - | - | - | HB  | - | - |
| USF12-125 FR        | 125 | 12 | - | - | - | - | - | V-0 | - | - |
| USF12-150           | 150 | 12 | - | - | - | - | - | HB  | - | - |
| USF12-150 FR        | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| USF12-180           | 180 | 12 | - | - | - | - | - | HB  | - | - |
| USF12-180 FR        | 180 | 12 | - | - | - | - | - | V-0 | - | - |
| USF12-55            | 55  | 12 | - | - | - | - | - | HB  | - | - |
| USF12-55 FR         | 55  | 12 | - | - | - | - | - | V-0 | - | - |
| USF12-75            | 75  | 12 | - | - | - | - | - | HB  | - | - |
| USF12-75 FR         | 75  | 12 | - | - | - | - | - | V-0 | - | - |
| USF12-90            | 90  | 12 | - | - | - | - | - | HB  | - | - |
| USF12-90 FR         | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-10            | 10  | 12 | - | - | - | - | - | HB  | - | - |

|              |     |    |   |   |   |   |   |     |   |   |
|--------------|-----|----|---|---|---|---|---|-----|---|---|
| USL12-100    | 100 | 12 | - | - | - | - | - | HB  | - | - |
| USL12-100 FR | 100 | 12 | - | - | - | - | - | V-0 | - | - |

|              |     |    |   |   |   |   |   |     |   |   |
|--------------|-----|----|---|---|---|---|---|-----|---|---|
| USL12-100 FR | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-12     | 12  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-120    | 120 | 12 | - | - | - | - | - | HB  | - | - |
| USL12-120 FR | 120 | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-14     | 14  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-140    | 140 | 12 | - | - | - | - | - | HB  | - | - |
| USL12-140 FR | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-150    | 150 | 12 | - | - | - | - | - | HB  | - | - |
| USL12-150 FR | 150 | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-18     | 18  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-20     | 20  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-200    | 200 | 12 | - | - | - | - | - | HB  | - | - |
| USL12-200 FR | 200 | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-230    | 230 | 12 | - | - | - | - | - | HB  | - | - |
| USL12-24     | 24  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-24 FR  | 24  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-24H    | 24  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-250    | 250 | 12 | - | - | - | - | - | HB  | - | - |
| USL12-26     | 26  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-26 FR  | 26  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-28     | 28  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-28 FR  | 28  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-28H    | 24  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-28H FR | 28  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-38     | 38  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-38 FR  | 38  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-40     | 40  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-40 FR  | 40  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-45     | 45  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-45 FR  | 45  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-50     | 50  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-50 FR  | 50  | 12 | - | - | - | - | - | V-0 | - | - |

|             |    |    |   |   |   |   |   |     |   |   |
|-------------|----|----|---|---|---|---|---|-----|---|---|
| USL12-55    | 55 | 12 | - | - | - | - | - | HB  | - | - |
| USL12-55 FR | 55 | 12 | - | - | - | - | - | V-0 | - | - |

|              |     |    |   |   |   |   |   |     |   |   |
|--------------|-----|----|---|---|---|---|---|-----|---|---|
| USL12-55 FR  | 55  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-60     | 60  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-60 FR  | 60  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-65     | 65  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-65 FR  | 65  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-7.0    | 7   | 12 | - | - | - | - | - | HB  | - | - |
| USL12-7.0 FR | 7   | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-7.2    | 7.2 | 12 | - | - | - | - | - | HB  | - | - |
| USL12-70     | 70  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-70 FR  | 70  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-75     | 75  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-75 FR  | 75  | 12 | - | - | - | - | - | V-0 | - | - |
| USL12-75H    | 75  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-8.5    | 8.5 | 12 | - | - | - | - | - | HB  | - | - |
| USL12-90H    | 90  | 12 | - | - | - | - | - | HB  | - | - |
| USL12-90H FR | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| USL6-100     | 100 | 6  | - | - | - | - | - | HB  | - | - |
| USL6-100 FR  | 100 | 6  | - | - | - | - | - | V-0 | - | - |
| USL6-120     | 120 | 6  | - | - | - | - | - | HB  | - | - |
| USL6-120 FR  | 120 | 6  | - | - | - | - | - | V-0 | - | - |
| USL6-150     | 150 | 6  | - | - | - | - | - | HB  | - | - |
| USL6-150 FR  | 150 | 6  | - | - | - | - | - | V-0 | - | - |
| USL6-20      | 20  | 6  | - | - | - | - | - | HB  | - | - |
| USL6-20 FR   | 20  | 6  | - | - | - | - | - | V-0 | - | - |
| USL6-200     | 200 | 6  | - | - | - | - | - | HB  | - | - |
| USL6-200 FR  | 200 | 6  | - | - | - | - | - | V-0 | - | - |
| USL6-36      | 36  | 6  | - | - | - | - | - | HB  | - | - |
| USL6-36 FR   | 36  | 6  | - | - | - | - | - | V-0 | - | - |
| USL6-60      | 60  | 6  | - | - | - | - | - | HB  | - | - |
| USL6-60 FR   | 60  | 6  | - | - | - | - | - | V-0 | - | - |
| USX12-100    | 100 | 12 | - | - | - | - | - | HB  | - | - |
| USX12-100 FR | 100 | 12 | - | - | - | - | - | V-0 | - | - |

|             |    |    |   |   |   |   |   |     |   |   |
|-------------|----|----|---|---|---|---|---|-----|---|---|
| USX12-12    | 14 | 12 | - | - | - | - | - | HB  | - | - |
| USX12-12 FR | 14 | 12 | - | - | - | - | - | V-0 | - | - |

|              |      |    |   |   |   |   |   |     |   |   |
|--------------|------|----|---|---|---|---|---|-----|---|---|
| USX12-12 FR  | 14   | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-120    | 120  | 12 | - | - | - | - | - | HB  | - | - |
| USX12-120 FR | 120  | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-150    | 150  | 12 | - | - | - | - | - | HB  | - | - |
| USX12-150 FR | 150  | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-18     | 20   | 12 | - | - | - | - | - | HB  | - | - |
| USX12-18 FR  | 20   | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-2.2    | 2.3  | 12 | - | - | - | - | - | HB  | - | - |
| USX12-2.2 FR | 2.3  | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-200    | 200  | 12 | - | - | - | - | - | HB  | - | - |
| USX12-200 FR | 200  | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-24     | 26   | 12 | - | - | - | - | - | HB  | - | - |
| USX12-24 FR  | 26   | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-3.2    | 3.2  | 12 | - | - | - | - | - | HB  | - | - |
| USX12-3.2 FR | 3.2  | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-38     | 38   | 12 | - | - | - | - | - | HB  | - | - |
| USX12-38 FR  | 38   | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-5.4    | 5.4  | 12 | - | - | - | - | - | HB  | - | - |
| USX12-5.4 FR | 5.4  | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-65     | 65   | 12 | - | - | - | - | - | HB  | - | - |
| USX12-65 FR  | 65   | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-7.0    | 7.2  | 12 | - | - | - | - | - | HB  | - | - |
| USX12-7.0 FR | 7.2  | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-7.6    | 7.6  | 12 | - | - | - | - | - | HB  | - | - |
| USX12-7.6 FR | 7.6  | 12 | - | - | - | - | - | V-0 | - | - |
| USX12-72     | 72   | 12 | - | - | - | - | - | HB  | - | - |
| USX12-72 FR  | 72   | 12 | - | - | - | - | - | V-0 | - | - |
| USX2-100     | 100  | 2  | - | - | - | - | - | HB  | - | - |
| USX2-100 FR  | 100  | 2  | - | - | - | - | - | V-0 | - | - |
| USX2-1000    | 1000 | 2  | - | - | - | - | - | HB  | - | - |
| USX2-1000 FR | 1000 | 2  | - | - | - | - | - | V-0 | - | - |
| USX2-1000H   | 1000 | 2  | - | - | - | - | - | HB  | - | - |

|               |      |   |   |   |   |   |   |     |   |   |
|---------------|------|---|---|---|---|---|---|-----|---|---|
| USX2-1000H FR | 1000 | 2 | - | - | - | - | - | V-0 | - | - |
|---------------|------|---|---|---|---|---|---|-----|---|---|

|               |      |   |   |   |   |   |   |     |   |   |
|---------------|------|---|---|---|---|---|---|-----|---|---|
| USX2-120      | 1200 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-120 FR   | 1200 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-1200     | 1200 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-1200 FR  | 1200 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-1200H    | 1200 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-1200H FR | 1200 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-130      | 130  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-130 FR   | 130  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-150      | 150  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-150 FR   | 150  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-1500     | 1500 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-1500 FR  | 1500 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-1500H    | 1500 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-1500H FR | 1500 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-1800     | 1800 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-1800 FR  | 1800 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-200      | 200  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-200 FR   | 200  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-2000     | 2000 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-2000 FR  | 2000 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-2000H    | 2000 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-2000H FR | 2000 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-250      | 250  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-250 FR   | 250  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-2500     | 2500 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-2500 FR  | 2500 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-300      | 300  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-300 FR   | 300  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-3000     | 3000 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-3000 FR  | 3000 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-3000H    | 3000 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-3000H FR | 3000 | 2 | - | - | - | - | - | V-0 | - | - |

|             |     |   |   |   |   |   |   |     |   |   |
|-------------|-----|---|---|---|---|---|---|-----|---|---|
| USX2-350    | 350 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-350 FR | 350 | 2 | - | - | - | - | - | V-0 | - | - |

|              |      |   |   |   |   |   |   |     |   |   |
|--------------|------|---|---|---|---|---|---|-----|---|---|
| USX2-350 FR  | 350  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-3500    | 3500 | 2 | - | - | - | - | - | HB  | - | - |
| USX2-3500 FR | 3500 | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-400     | 400  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-400 FR  | 400  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-450     | 450  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-450 FR  | 450  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-500     | 500  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-500 FR  | 500  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-600     | 600  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-600 FR  | 600  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-65      | 65   | 2 | - | - | - | - | - | HB  | - | - |
| USX2-65 FR   | 65   | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-700     | 700  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-700 FR  | 700  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-72      | 75   | 2 | - | - | - | - | - | HB  | - | - |
| USX2-72 FR   | 75   | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-800     | 800  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-800 FR  | 800  | 2 | - | - | - | - | - | V-0 | - | - |
| USX2-900     | 900  | 2 | - | - | - | - | - | HB  | - | - |
| USX2-900 FR  | 900  | 2 | - | - | - | - | - | V-0 | - | - |
| USX6-100     | 100  | 6 | - | - | - | - | - | HB  | - | - |
| USX6-100 FR  | 100  | 6 | - | - | - | - | - | V-0 | - | - |
| USX6-120     | 120  | 6 | - | - | - | - | - | HB  | - | - |
| USX6-120 FR  | 120  | 6 | - | - | - | - | - | V-0 | - | - |
| USX6-150     | 150  | 6 | - | - | - | - | - | HB  | - | - |
| USX6-150 FR  | 150  | 6 | - | - | - | - | - | V-0 | - | - |
| USX6-200     | 200  | 6 | - | - | - | - | - | HB  | - | - |
| USX6-200 FR  | 200  | 6 | - | - | - | - | - | V-0 | - | - |
| VGS1000      | 1000 | 2 | - | - | - | - | - | HB  | - | - |
| VGS1500      | 1500 | 2 | - | - | - | - | - | HB  | - | - |
| VGS2000      | 2000 | 2 | - | - | - | - | - | HB  | - | - |

|        |     |   |   |   |   |   |   |    |   |   |
|--------|-----|---|---|---|---|---|---|----|---|---|
| VGS300 | 300 | 2 | - | - | - | - | - | HB | - | - |
| VGS100 | 100 | 2 | - | - | - | - | - | HB | - | - |

|                                       |     |    |   |   |   |   |   |     |   |   |
|---------------------------------------|-----|----|---|---|---|---|---|-----|---|---|
| <b>VGS420</b>                         | 420 | 2  | - | - | - | - | - | HB  | - | - |
| <b>VGS500</b>                         | 490 | 2  | - | - | - | - | - | HB  | - | - |
| <b>VGS600</b>                         | 600 | 2  | - | - | - | - | - | HB  | - | - |
| <b>VGS800</b>                         | 800 | 2  | - | - | - | - | - | HB  | - | - |
| <b>XP12-100 FR, 174-8863</b>          | 28  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-100, CT12-90W</b>             | 28  | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP12-150 FR</b>                    | 33  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-150, CT12-150W</b>            | 33  | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP12-210 FR</b>                    | 55  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-210, CT12-225W</b>            | 55  | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP12-240</b>                       | 55  | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP12-240 FR</b>                    | 55  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-300 FR</b>                    | 80  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-300, CT12-320W</b>            | 80  | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP12-350 FR</b>                    | 90  | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-350, CT12-370W, XP12V3000</b> | 90  | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP12-400 FR</b>                    | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-400, CT12-430W, XP12V3400</b> | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP12-430</b>                       | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP12-430 FR</b>                    | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-490</b>                       | 140 | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP12-490 FR</b>                    | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-490LP</b>                     | 100 | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP12-490LP FR</b>                  | 100 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-540 FR</b>                    | 140 | 12 | - | - | - | - | - | V-0 | - | - |
| <b>XP12-540, CT12-540W</b>            | 140 | 12 | - | - | - | - | - | HB  | - | - |
| <b>XP6-620</b>                        | 200 | 6  | - | - | - | - | - | HB  | - | - |
| <b>XP6-620 FR</b>                     | 200 | 6  | - | - | - | - | - | V-0 | - | - |
| <b>DJM12300</b>                       | 300 | 12 | - | - | - | - | - | HB  | - | - |



ORIGIN BATTERY  
Maintenance Free, Sealed Lead Acid Battery

**IEP**

**NITRO**

**FASTERHOLT**

**Ultracell**® CHAMBERLAIN GROUP *Puli* *Schumacher* **IBM**  
ENERGY

**CE** **CE** **Schumacher** **BluePoint** **Snap-on**

**DieHard** **DSR** PRO SERIES **WAGNER** **LiftMaster** **Truman** **Powermeister**

**HAWK** **LEADER** **Crystalite** **EXCEL** **LD** **GO2POWER** **Voltem**

**BELINTRA** **NGS** **Access** **CIL** **Outlast** **LIDO**

**ECCO** **IDEALPOWER** **JUSTSTANDOUT** **UPLUS**  
NEW TECHNOLOGY BATTERY

**BATTERY** **SLA** **MSB** **Sunite**

and model designation and the Recognized Component Mark,

Last Updated on 2022-10-28

The appearance of a company's name or product in this database does not in itself assure that products so identified have been manufactured under UL Solutions' Follow - Up Service. Only those products bearing the UL Mark should be considered to be Certified and covered under UL Solutions' Follow - Up Service. Always look for the Mark on the product.

UL Solutions permits the reproduction of the material contained in Product iQ subject to the following conditions: 1. The Guide Information, Assemblies, Constructions, Designs, Systems, and/or Certifications (files) must be presented in their entirety and in a non-misleading manner, without any manipulation of the data (or drawings). 2. The statement "Reprinted from Product iQ with permission from UL Solutions" must appear adjacent to the extracted material. In addition, the reprinted material must include a copyright notice in the following format: "©2022 UL LLC."